

824 WindowTouch4^e


Operation Manual






© 2012 HAEGER, INC. All rights reserved. No part of this work may be reproduced, copied, adapted, or transmitted in any form or by any means without written permission from HAEGER, INC. HAEGER, INC makes no representation or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Further, HAEGER, INC reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation to notify any person of such revision or changes.

Table of Contents

SECTION 1 - INTRODUCTION	7
Congratulations!	7
Haeger Locations Worldwide	7
Statement of Foreseen Use	9
Safety Information (also see section 3)	9
Customer Service (also see section 6)	9
Responsibilities of the Operator	9
Responsibilities of the Service Technician	10
Quality of Parts & Fasteners	10
Basic data sheet	11
Illustration of safety notes	12
Details of location in the documentation	13
Safety precautions and warnings	14
SECTION 2 - INSTALLATION	15
Handling	15
Recommended Safe Work Zone	16
Skid removal	17
Machine setup	18
Main power set-up	20
Machine operator basic controls	21
Testing of the electrical set-up	23
The Upper Tool Holder	25
The Turret Insertion System (T.I.S.)	26
Tooling storage	27
Quick mount mutli-shuttle	28
Quick mount TIS-3	29
Quick Mount Auto Tooling	30
Modular Auto Feed System (MAS 350)	31
Conductive mode set-up procedure	32
Getting started – Before you turn on the machine	32
Setting the machine	32
Checking the up travel & insertion	32
Non-conductive mode set-up procedure	34

Getting started – Before you turn on the machine	34
Setting the machine	34
Checking the up travel & insertion	34
SECTION 3 – HAEGER SAFETY SYSTEM	36
Safety system description.....	37
Conductive Mode	37
Non-conductive mode	37
How the safety system works.....	37
Lockout-Tagout.....	39
Fire Safety Equipment	42
Safety Awareness & Residual Risks.....	43
Introduction	43
1. Situations and Actions to Avoid	43
2. Residual Safety Risks	43
Operator Safety Awareness & Residual Risks	44
Maintenance Safety Awareness & Residual Risks	46
Safety System Tests.....	47
Step 1: Safety switch test procedure	47
Step 2: conductive mode test	49
Step 3: Non-conductive mode test	51
SECTION 4 – TOUCH SCREEN OPERATION (Step by Step Demo)	53
Window Touch-4e - Introduction	53
Touch Screen Hierarchy Overview	54
 Quick Run Step by Step Demo	56
User Login	57
Password.....	57
Input 1: Station	58
Input 2: Material	58
Input 3: Fastener	58
Input 4: Unit & Size	59
Input 5: Insertion Values	59
Force (LBS)	59
Dwell (Sec).....	60
Up Travel (%).....	60
Input 6: MAS Values	60
Eject Time (Sec).....	60
Vibration (%)	61
Vibration Time (Sec).....	61
Input 7: Quality Control	61
Tooling Protection System (TPS).....	61
Fastener Length	62
Fastener Detection.....	62
Input: Status	62
Clamp	62
Vacuum	63

Tooling.....	63
Modular Auto Feed System (MAS).....	63
Eject Fastener.....	64
Setup Stroke.....	64
 Programs Setup Step by Step Demo	66
User Login	68
Password.....	68
Programs.....	69
Create New Program	69
Program Name.....	69
New Customer	70
Program Notes.....	70
Fastener Differentiation	70
Program Wizard (Automatic or Manual, Station 1 of 4).....	71
1. Preset:	71
Library.....	71
Part Material.....	71
2. Fastener:	71
Manufacturer.....	71
Type	72
3. Size	72
Unit of Measure.....	72
Fastener Length	72
Part Identification	72
4. Select Tooling Type	73
Program Wizard (Manual, Station 2 of 4).....	73
Program Wizard (Manual, Station 3 of 4).....	75
Program Wizard (Manual, Station 4 of 4).....	76
Add Insertion Group (Station 1)	78
Amount	78
Part Image.....	79
Location: USB HDD.....	79
Select Insertion Points	80
Add Insertion Group (Station 2)	81
Add Insertion Group (Station 3)	83
Add Insertion Group (Station 4)	85
Insertion Group Program <u>Correction Example</u> (Station 3)	88
Save Program.....	91
 Run Program Step by Step Demo.....	92
User Login	94
Password.....	95
Production Run Overview.....	96
Batch Size.....	96
Parts Completed	96
MAS Vibration (%)	96
MAS.....	96

Preview	96
Station 1 Insertion – Start Production	97
Setup Stroke	97
Adjusting Insertion Values	98
Another Setup Stroke Is Required After Adjustments	99
Station 2 Insertion	102
Station 3 Insertion	105
Station 4 Insertion	108
SECTION 5 - OPTIONS	112
SECTION 6 – MACHINE MAINTENANCE	113
Maintenance Schedule	113
Trouble Shooting	115
Weekly Care & Maintenance	124
(MAS 350): Care & Maintenance	124
Flight Tube: Care & Maintenance	125
Upper Tool Changer: Care & Maintenance	126
Upper Tool Holder: Care & Maintenance	127
 Diagnostics: From Main Screen	128
PLC1 I/O Screen	129
PLC I/O	130
Schematics & Diagrams	131
Customer Service	132
SERVICE TEAM	133
Warranty	134
SECTION 7 – PARTS LIST	135
Description	135
Parts List - Main Assembly	136
Parts List - MAS 350 Bowl Assembly	138
Parts List – Upper Tool Holder Assembly	140
Parts List - Quick Mount Assembly	141
Parts List - Muti-Shuttle 2 Assembly	143
Parts List - HMI Arm Assembly	145
Parts List - TIS Assembly	147
Parts List - Vacuum Generator Assembly	150
Parts List – Service Tray Assembly	151
Parts List – Positive Stop System Assembly	152
Parts List – Hydraulic Cylinder Main Assembly	153
Parts List – Electrical Cabinet High/Low Voltage Assembly	155
Parts List – Printed Circuit Board Assembly	157
Parts List – Hydraulic Reservoir Assembly	158
Parts List – Hydraulic Manifold Assembly	161

Parts List – Hydraulic Suction Filter Assembly.....	163
Parts List – Return Filter Assembly	164
Parts List – Motor Pump Assembly.....	165
Parts List – Hydraulic Cooler Assembly.....	166
Decommissioning Your Machine	167



SECTION 1 - INTRODUCTION

Congratulations!

You are using a genuine Haeger Hardware Insertion Machine - the industry standard for dependable fastener insertion.

Haeger, Inc. is widely recognized as the industry leader in the development and implementation of innovative self-clinching fastener installation technologies. For over twenty years, Haeger engineers have been designing and building flexible systems for installing practically every kind of self-clinching fastener into practically every kind of work piece - creating new technologies to help Haeger owners get just about any job done productively and profitably.

Over the years, Haeger's innovative tooling and patented quick-change automatic fastener feeding systems have revolutionized the way the world's fabricators and manufacturers install hardware.

So whenever your operation faces an insertion challenge, turn to the manufacturer with the most experience in developing self-clinching fastener insertion solutions. Turn to Haeger.

Haeger Locations Worldwide

Corporate Headquarters

811 Wakefield Drive
Oakdale, California 95361
USA
(800) 878-4343
(209) 848-4000
Fax: (209) 847-6553

Haeger Europe

Textielstraat 18
7575 CA Oldenzaal
The Netherlands
Phone: +31 541 530 230
Fax: +31 541 532 400

EC DECLARATION OF CONFORMITY

Manufacturer & Address:

Haeger, Inc.
811 Wakefield Drive
Oakdale, California 95361
USA

Authorized to Compile Technical File Contact:

Wouter Kleizen
Haeger Europe
Textielstraat 18
7575 CA Oldenzaal
The Netherlands

We declare under our sole responsibility that the product identified as:

Equipment Name: **824 WindowTouch -4e**
Equipment Description: **Fastener Hardware Insertion Machine**
Model: **824 WT -4 H or L**
Serial Number: **8WT4xxxx**

To which this declaration relates is in conformity with the following standards:

Directives 2006/42/EC, Machinery
Directive 2004/108/EC, Electromagnetic Compatibility

And conformity to relevant directives/standards/and or provisions where appropriate:

EN 349: 1993 +A1:2008	ISO 60204-1: 2006 +A1:2009	ISO 12100-1: 2010
EN 982: 1996 +A1:2008	ISO 14121-1: 2007	ISO 12100-2: 2010
EN 953: 1997 +A1:2009	ISO 13849-1: 2008	

Statement of Foreseen Use

The WindowTouch-4e insertion machines are intended for use in an indoor commercial or industrial environment. Factory-authorized training is made available for operators at the time of installation. The Insertion Logic technology and All Haeger machines are designed to operate at voltages ranging between 208 – 575V and at 50/60Hz with no additional power requirements. Haeger systems do not produce thermal, biological, fire or radiation hazards etc. Again, Haeger machines are not intended or designed to be used in hazardous or explosive environments, exposure to outside elements of weather such as freezing, wet, extreme high temperatures or extreme dusty environments. See your local representative or visit <http://haeger.com> for more details.

Safety Information (also see section 3)

This manual contains details on safety when using your new machine. Also, where applicable, cautions and warnings are used throughout this manual to draw your attention to safety precautions. The Haeger Safety System section of this manual, explains the safety features built into the machine that minimizes the dangers of pinching or crushing while operating the machine.



It is recommended that in addition the safety details in this Haeger insertion machine manual, all customers, create, implement and maintain their own individual safety codes, policies and procedures.

Customer Service (also see section 6)

If your machine malfunctions and you are unable to resolve the problem, field service technicians can be dispatched to your site to conduct repairs. Service visits are paid for by the customer, either under a maintenance agreement, by purchase order or prepayment. Time and material rates are charged for any service not covered under a maintenance agreement. Before calling to report a problem, gather as much information about the problem as possible and have it ready to provide to your customer care center. The more information you can provide initially, the more quickly the problem can be corrected.

Responsibilities of the Operator

The machine operator must be properly trained. Haeger provides training for the operator in the use of the machine and software at the time of installation. It is the customer's responsibility to ensure that only properly trained personnel operate the machine. Operators must be fully versed in its operation. For any operator unfamiliar with its operation, training is required. Training is available; contact your Haeger representative. The customer must also ensure that all operators are aware of the safety issues described in this manual. The operator or other trained personnel are expected to handle all user maintenance as detailed in the User Manual. If your site has a technician in charge of machine maintenance, that person is the optimal candidate. While any trained operator may perform routine maintenance, the best maintenance results from familiarity with the machines internal operation and history. The machine requires daily maintenance to ensure the highest insertion quality and longer life for the machine. The machine design provides you easy access to perform this simple task and it is essential that machine maintenance is performed as described in the **“Maintenance Schedule”** section of this manual. It is the responsibility of the operator to try to eliminate simple problems before calling a service representative. But knowing when to call for

service is also important. An untrained operator must not attempt to service the machine as this may cause further damage. When you have determined that a service call is required, call as soon as possible. See the Troubleshooting and Maintenance sections for more details.

Responsibilities of the Service Technician

Field service technicians must have machine and InsertionLogic® service training. The service technician is responsible for all repairs, upgrading and modification requested by the customer or mandated by the Haeger Service and Support Group. The service technician who installs the machine will also provide training for the operator that covers all of the basic skills and safety practices required to operate the machine. Service personnel must be furnished with proper tools for the installation and maintenance of the machine.

Quality of Parts & Fasteners

The WindowTouch -4e is designed and engineered for high volume installation of self-clinching fasteners of all types and sizes. As a rule, the “quality” of parts and fasteners is very important to getting the most out of your WindowTouch -4e machine. The next two paragraphs are general in nature but critical to maximizing productivity, quality and profit potential.

Fastener Quality Basics: In general, self-clinching fasteners are designed with an annular recess in the shank that allows the softer metal of your part (work piece) to cold form in and around it and permanently lock the fastener in place. Inspecting the fasteners on a regular basis and verifying they are constructed with in design tolerances is very important. With studs and stand-offs, this is especially critical as they increase in length. We highly recommend coordination between yourself and the fastener supplier to determine the acceptable dimensional tolerances and force requirements for your particular application in an effort to achieve consistent quality.

Part Quality Basics: Take special care in inspecting all parts in which the fasteners will be inserted. Verify the holes in the part meet the required specifications and tolerances. In addition, visually inspect each part, looking for burrs and irregularities around each hole. Holes out of tolerance, burrs and irregularities will degrade the fastener’s performance and may cause difficulties during the insertion process. We also recommend developing a consistent method of handling or holding the part (work piece) during the insertion process to ensure quality and increase fastener performance long term.



- Self-clinching fasteners should be tested to be sure they meet manufacturer’s published performance data or specifications specific to the application.

Basic data sheet

YOUR Machine Model 824 WindowTouch 4e

Serial Number:	<input type="text"/>	Year Manufactured:	<input type="text"/>
Voltage:	<input type="text"/>	Amperes:	<input type="text"/>
Hertz (Machine):	<input type="text"/>	Hertz (MAS):	<input type="text"/>
Phase:	<input type="text" value="3"/>		

824 WindowTouch 4e Machine Matrix

Voltage	208/220	380/480	575
Amperage	17	9.6	6.1
Hertz	50 or 60	50 or 60	50 or 60
Phase	3	3	3

Noise Measurement Summary

Emissions Noise Sensitivity	Maximum Measured Value
	In normal operation
A weighted pressure level	87db
C weighted pressure level	87db
-- For all locations, Noise protection is always recommended. --	

Fluids & Pressure

Hydraulic Oil:*	AW Exxon Humble Hydraulic. H
ISO Viscosity:	32
Capacity:	22 gallons/83 liters
Max. Operating Pressure:	2,450 psi/169 bar
* Equivalent hydraulic oils may be used. It is the machine owner's responsibility to determine which hydraulic oils in their area are equivalent to ISO 32.	

Dimensions

Height:	90 in./2268 mm
Width:	32 in./813 mm
Depth:	56 in./1422 mm
Weight:	2900 lb./1131 kg

Illustration of safety notes

Safety notes are identified by a pictogram and a signal word. The signal word describes the severity of the risk at hand.



Warning possible dangerous situation that could cause minor physical injuries.



Risk of electrical voltage possible dangerous situation that could cause serious physical injuries.



Risk of crush injuries possible dangerous situation that could cause serious physical injuries.



Risk of pinching injuries possible dangerous situation that could cause serious physical injuries.



Important for a special behaviour or activity for the safe handling of the machinery.



Application tips and particularly useful information.



Stop! Contact your Haeger Representative for instructions on how to proceed.



Eye protection must be worn when operating this machine




Read First! Read instructions first before operating this machine. Make sure that you read and understand all of the descriptions, instructions and notes contained in this section. Follow all of the Warnings and Cautions in this manual. **Your safety and productivity depend on it.**



The Haeger 824 WindowTouch was designed to conform to applicable ANSI, OSHA, and CSA safety standards. It is the user's responsibility to understand any specific local safety codes that may require additional guarding and conform to those standards.

Details of location in the documentation

All information in these instructions concerning direction and location refer to the workplace of the operator.



In this manual, the use of the terms left and right refers to the machine operator's left and right when they are standing in front of the machine, facing the work area between the Upper Tool



Eye protection must be worn when operating this machine

Safety precautions and warnings



Never

Operate this Haeger Hardware Insertion Machine without proper instructions. Read and thoroughly understand this manual before attempting to operate this machine.



Never

Tamper with any part of this machine's electrical system unless you are a trained electrician and thoroughly understand this machine's electrical schematic.



Never

Operate this machine while wearing any metal objects (i.e., rings, watches, bracelets, etc.) that may come into contact with the *Upper Tool*, *Lower Tool* or work piece.



Never

Attempt to test or demonstrate this machine's Safety System by placing any portion of your hand or body between the *Upper* and *Lower* tools. Always use the test procedure outlined in Section 4 of this manual.



Never

Exceed the maximum force of 9,000 pounds on the J- Frame and the *Square Tipped Tool Holder*.



Never

Attempt to run any irregular shaped sheet metal part that could contact the *Upper* and *Lower Tools* **before** these tools insert the fastener into the part. This applies to both the *Conductive* and *Non- Conductive Modes* of operation.



Never

Press the *Down Footswitch* a second time in the *Non-Conductive Mode* when your hands are in the area of the tooling.



Never

Operate this Machine without wearing the proper eye protection



Eye protection must be worn when operating this machine



The Safety System's heavy duty retractable electrical cord is very durable; however caution should be taken when working close to the edge of deep boxes or cans. Operating with the Safety System's electrical cord too close to sharp metal edges may damage the cord.



Lubricate the *Upper Tool Holder* with a small amount of lithium (white) grease. Any other lubricant may interfere with the Safety System's operation and will void your machine warrant

SECTION 2 - INSTALLATION

Handling

The Haeger Hardware Insertion Machine is designed to provide the operator with a comfortable working height and to allow freedom of movement when positioning work pieces in the tooling area. Because of these features, the machine is **top heavy when unloading**.



- Handle with **extreme caution!**
- **Never** attempt to move the machine with a forklift positioned in **front of or on either side** of the machine.
- **Always** position the forklift or pallet truck to the **rear** of the machine when moving the machine with a forklift or pallet truck.



NEVER lift machine from the **FRONT** or the **SIDE** – **IN** OR **OUT** OF THE **BOX**.




ALWAYS Position the forklift to **REAR** of the machine.



Machine is **HEAVY** in the **REAR** and will tilt back when lifted with lift strap.

Recommended Safe Work Zone

It is recommended that prior to delivery, the customer layout an area in their facility that allows the operator and maintenance personal, ample space to work or service the machine. The distances shown below are recommendations. It is the customer's responsibility to adjust the "Safe Work Zone" based on their own individual needs to optimize operator and service technician safety. We also recommend that the customer and/or operator inform facility visitors of the "SAFE WORK ZONE" around the machine to minimize or eliminate the possibility of accidental bumping of the operator while the machine is in operation.



RECOMMENDED MINIMUM SAFE WORK ZONE

* The overall Safe Work Zone Dimensions will vary depending on the size of the part or work piece you are producing. It is generally recommended to have a 3' (1 m) to 4' (1.22 m) minimum safe zone beyond the operator and work piece to maneuver the part into position ready for insertion(s). In addition, the Safe Work Zone provides ample space for the service technician to service the machine.

Skid removal




- The feet are already installed on the machine.
- You will need to lift the machine to remove the skids.
- You will need to open three wrenches to adjust the feet.

Skid Bolt: 9/16 in./13mm socket



9/16"/13mm socket wrench

Foot: 7/8 in./22 mm open end wrench



7/8 in./22 mm

15/16 in./24 mm open end wrench



15/16 in./24 mm

1. Uncrate the machine.
2. Remove the (8) lag screws that hold the machine base to the shipping skid (2 on each plate).
3. Use the strap on the top of the machine frame and an appropriate sling for the weight of this machine and lift it until it clears the skids.


The weight of the Haeger Hardware Insertion Machine and skids are as follows:

Machine	Pounds	Kilograms
824 Window Touch 4e	2900 lb.	1315 kg.

4. Carefully move the machine away from the skids (or move the skids). Lower the machine onto the floor.
5. Lower the nut on the foot and remove the plate.
6. Tighten the foot nut until it is flush with the bottom of the machine's base.

Machine setup

1. Carefully locate the machine in the shop on a flat and preferably level hard surface such able to with withstand the weight of the machine as described it the “Basic Data” paragraph of this manual. If there is any question on the ability of the sub-surface to support the weight of the machine, check with a structural engineer. As of this publication there are no know requirements for fixing or anchoring the machine to the sub-surface, check with your local building code official, agency or structural engineer in your area to verify.
2. Level it front to back and left to right using the top surface of the Lower Tool Holder as a reference surface (see Figure below) Using a 7/8 in./22 mm wrench to adjust the feet, level the machine left to right and front to back. Make sure that all of the machine’s feet are securely resting on the shop floor.
3. Without changing the height adjustment of the feet, tighten the lock nut on each foot using a 15/16 in./24 mm wrench.



Machine setup (continued)


If the machine is equipped with a Modular Autofeed System (MAS):

- Air must be connected to the fitting on the black hose which extends down from the bottom of the MAS. Connect an air line that is capable of delivering of clean, dry air. For further instructions, reference the Modular Auto Feeder Operation and Maintenance Manual Section of this manual.

Air Flow	Air Pressure
3 ft ³ /min - 85 l/min	90 psi/620 kPa 2-3 CFM

- If the machine is not yet filled with oil, remove the sides of the machine. Fill the machine with AW Exxon Humble Hydraulic H or equivalent premium hydraulic oil. Replace the sides when finished.

Fill the reservoir of the machine with the amount of hydraulic oil listed below:		
Machine	Gallons	Liters
824 Window Touch 4e	22	83



Main power set-up



- The electrical connections required in this section must be made by a qualified electrician.
- Check to make sure that the electrical power supply for this machine has been disconnected at the supply source before doing any work on the machine's electrical system.

1. Check the voltage on the Machine Nameplate, located on the rear of the machine's Main Electrical Cabinet (see Figure 2.3). **!** **MAKE SURE** the machine's incoming shop voltage is the same as the voltage the machine has been wired for. If the voltages do not match, **STOP!** Contact your Haeger Representative for instructions on how to proceed.
2. Ensure that the machine's electrical power supply has been disconnected at the supply source. Turn the machine's Main Disconnect Switch to the Off position. Using the special key, open the door of the Main Electrical Control Cabinet (see Figure 2.4).
3. Wire the incoming three phase electrical power to the three connectors on the Main Disconnect Switch terminals labeled L1, L2 and L3. Make sure the machine is properly grounded by connecting the incoming ground wire to the top terminal of the green and yellow terminal block on the right side of the Main Disconnect Switch.
4. After all electrical connections have been properly made, we recommend installing service loops and/or an angle bracket (not included) on the main power cord coming in through the rear of the machine. Service loops provide a means of securing the main power cord to the electrical cabinet. In addition, it provides strain relief and unnecessary wire chafing.
5. Close and latch the Main Electrical Control Cabinet door using the special key.
6. Install the computer into the front of the computer cabinet and secure with fasteners supplied.




Figure 2.4




Figure 2.3

Check the voltage on the Machine

Machine operator basic controls

All the operator controls are located on the front and right side of machine front cover, except the foot pedal, this includes the Touch Screen, the E-Stop button/Stop button and Power ON button.



Touch Screen Control Panel

This is the primary interface to the operation control system. It is used for most of the machine's settings and functions. You will use the touch screen to enter information. The screen displays text and graphical information and allows the operator to make selections by touching different parts of the screen as indicated by what is displayed on the screen.



E-Stop Push Button

The **E-Stop Push Button** switch is used to shut the machine off in all situations. It is a two position switch with a red mushroom button. When pushed in, it latches, turns the machine's controls off and shuts down the machine's motor. **In the In position, the machine cannot be restarted.** To restart the machine, twist the red mushroom button clockwise. There is an arrow showing the direction on the mushroom button. The mushroom button will snap out and the machine can be restarted.



Machine Power ON Switch

The On Switch is a momentary contact push button switch with a light in it. When the On Switch is pushed, the machine's controls are turned on and the motor starts. The green light in the switch will also turn on. When the light is off, the machine's controls are off and the motor is stopped.



The Foot Pedal

Switches are used by the operator to control the start of an insertion.



Main Disconnect Switch

This switch controls power for all machine components (including the touch screen). Rotate clockwise to switch **ON** and counterclockwise to switch **OFF**.



Down/Up Footswitch

The Down/Up Footswitch is shielded and connected to the Haeger Hardware Insertion Machine by a heavy duty cable. It contains both the Down and Up Footswitches.


When the Down Footswitch is depressed, the Upper Tool Holder moves down. If you remove your foot from the Down Footswitch, the Upper Tool Holder will stop. If you depress the Down Footswitch again, the downward motion will start again.

Non-Conductive Mode:

- Turn key to the left.



Conductive Mode:

- Turn key to the Right.
-  Key is removable in this position and should **not** stay with the machine – key should be kept by a trained setup person or shop owner.

In **Conductive Mode**, the Hardware Insertion Machine will complete one normal cycle of the insertion process when the Down Footswitch is depressed and held down. Hold the Down Footswitch until the Upper Tool Holder starts to go up again.

In the **Non-Conductive Mode**, when the Down Footswitch is depressed, the Hardware Insertion Machine will lower the Upper Tool until it contacts the workpiece and then stop. The Down Footswitch must then be released. When the Down Footswitch is **depressed a second time**, the Hardware Insertion Machine **will exert the preset force** and then return to its Up position. Once the upward travel starts, release the Down Footswitch.

When the Up Footswitch is depressed, the Upper Tool Holder moves up. If you remove your foot from the Up Footswitch, the Upper Tool Holder will stop. If you depress the Up Footswitch again, the upward motion will start again.



Make sure you read and understand the Warning and Safety Instructions in the Introduction section of this manual and follow the instructions for testing the Safety System in the Safety System section before attempting to operate this Hardware Insertion Machine.



NEVER depress the Down foot switch a second time in Non-Conductive Mode when your hands are in the tooling area.

Testing of the electrical set-up



The Machine Setup must be completed before testing the electrical setup.

1. Turn the machine's Main Disconnect Switch to the On position



2. Twist the Red Mushroom Button clockwise to unlatch the off switch.



3. Have someone watch the motor rotation in the base of the machine; the motor has an orange arrow indicating the correct rotation direction. Press the *On* Button. The green light in the switch will turn on and the machine's motor will start.
4. If the motor rotates the same direction as the arrow, install the Side Panels on the Machine Base. The machine is now ready for use go to the *Upper Tool Holder* section.



If the motor **did not turn in the same direction as the arrow**, follow to the next series of steps.

Testing of the electrical set-up (continued)



- NEVER tamper with any part of this machine's electrical system unless you are a trained electrician and thoroughly understand this machine's electrical schematic.
- Check to make sure that the electrical power supply for this machine has been disconnected at the supply source before doing any work on the machine's electrical system.

Adjusting the Wiring if the Previous Step Failed

1. Disconnect the machine from its electrical power supply at the supply source.
2. After disconnecting the machine from its electrical power supply at the supply source, turn the machine's Main Disconnect Switch to the *Off* position.
3. Using the special Electrical latch key, open the door of the Main Electrical Control Cabinet.
4. Reverse the incoming electrical leads on terminals L2 and L3 of the Main Disconnect Switch (see electrical schematic)
5. Close and latch the door using the special key.
6. Turn the machine's Main Disconnect Switch to the *On* position.
7. Have someone watch the motor in the base of the machine when you turn the machine on. The motor has an orange arrow indicating the correct motor rotation. Press the *On* Button. The green light in the switch will turn on and the machine's motor will start.
8. If the motor turned the same direction as the arrow, install the Side Panels on the Machine Base. The machine is now ready for use.
9. If the motor **did not turn in the same direction as the arrow** contact your Haeger Representative for instructions.



Do not operate the machine without both the Upper and Lower Tools properly locked in place with the correct set screws and/or Quick Change Lever.



In this manual, the use of the terms left and right refers to the machine operator's left and right when they are standing in front of the machine, facing the work area between the Upper Tool Holder and Lower Tool Holder.

The Upper Tool Holder

The *Upper Tool Holder* is secured to the machine's cylinder rod by the black serrated knob on its right side. You can usually leave this Upper Tool Holder in the machine. If you do remove it, be very careful. There are continuity springs and guide pins inside the Upper Tool Holder. These items are **very important** part of the Haeger Safety System and **must not** be removed. If they are lost, do not operate the machine until they have been replaced.

Large tools, such as the One Touch vacuum anvil, are secured in the Upper Tool Holder by a M6 x 6 SHSS (Socket Head Set Screw) located on the right side of the Upper Tool Holder.

For smaller tools, such as the standard Manual Tooling line, a Standard Tool Adapter may be installed in the Upper Tool Holder using the same M6 x 6 SHSS. The smaller tools are held in the Standard Tool Adapter by another M6 x 6 SHSS also located on the right side of the Standard Tool Adapter.

When installing any tool or the Standard Tool Adapter, always make sure that it is pushed in as far as possible and is securely held by the M6 screw(s).



Important: If this thumb screw is lost, DO NOT replace it with just any length 5mm screw. Using too long of a screw will damage the safety switch.

– Haeger replacement part numbers:

11-00241 THUMB SCREW CAP

H-3738 SHCS, M5 x 0.8 x 12mm, BLACK OXIDE



Steps to Install an Upper Tool

1. Loosen the M5 set screw in the Tool Holder or Adapter.
2. Insert the tool into the Tool Holder or Adapter.
3. Tighten the M6 set screw until the tool is locked securely in place.




The Safety System's heavy duty retractable electrical cord is very durable; however, caution should be taken when working close to the edge of deep boxes or cans. Operating with the Safety System's electrical cord too close to sharp metal edges may damage the cord.

The Turret Insertion System (T.I.S.)



Do not operate the machine without both the Upper and Lower Tools properly locked in place with the correct set screws and/or Quick Change Lever.

The Lower Tool Holder is secured to the lower arm of the machine's frame by a M16 X 50SHCS (Socket Head Cap Screw). When this cap screw is loosened, the lower tool may be aligned to the upper tool. All Standard Haeger Lower Tools fit in the Lower Tool Holder without the need for any adapters.



To loosen or tighten the M16 X 50 SHCS you must turn the turret tool to gain access.

To align the Turret Tool:

1. Bring Upper tool down to just above lower turret with tool installed for alignment.
2. Turn the lower turret tool to gain access to the M16 X 50 SHCS.
3. Loosen the M16 X 50 SHCS and use the M16 X 60 SHCS on the back of the turret tool to move assembly forward or back.
4. Use the Side adjustment screws to align turret from side to side. .
5. Once alignment has been set Tighten the Hold down bolt M16 X 50 SHCS To 90 ft./ lbs.




Steps to Install a Lower Tool

1. Turn Turret to allow bolt to be put in under the turret tool arm.
2. Place the tool into the Lower Tool Holder.
3. Lock the tool into place in the Lower Tool Holder by tightening the bolt until the tool is locked securely in place.


Tooling storage

The integrated tooling storage cabinet allows for quick and easy accessibility and quick tool retrieval. Tools are now organized, that maximizes tool life and prevents lost tooling. Separate compartments are shown below.



Quick mount mutli-shuttle


The Multi-Shuttle is a 1-piece quick mount tooling module with quick release mounting. The module has an integrated built electrical/air supply connections and adjustable positive-locking alignment.



Step 1: Mount shuttle tooling to the bottom of multi-shuttle.





Step 2: Slide the multi-shuttle into the positive locking holder.




Step 3: Lock multi-shuttle in place.

Quick mount TIS-3



Quick Mount Auto Tooling

Installation and change over in two easy steps




Modular Auto Feed System (MAS 350)

Modular Auto Feed System (MAS): This system allows the operator to either run the MAS 350 at a continuous vibration or an intermittent vibration. Continuous vibration is commonly used when running the bowl out of hardware for a tooling change or for those small quantity hardware runs. Intermittent vibration is most commonly used for normal insertion applications where you have good quantity of hardware that will keep your multi module full at all times.



MAS 350 Bowl

- Fasteners vibrate up and around the MAS bowl
- Automatically lining up the fasteners at the doorway of the multi module



MAS 350 Quick Mount Assembly

- Air is ejected, moving the fastener through the tubing
- Positioning the fastener at the quick mount assembly, ready for insertion

Conductive mode set-up procedure



This procedure assumes that you are thoroughly familiar with this machine's controls as described in the first part of this section. If you are **not** familiar with these controls, **STOP**. Return to the beginning of this section and review any controls you are not thoroughly familiar with **before** continuing. If you have any questions, contact your Haeger Representative.



Depending on the ambient shop temperature, you may need to warm up your Haeger Hardware Insertion Machine before beginning any operations. To do this, turn it on and let it run for about ten minutes.

Getting started – Before you turn on the machine

1. Determine the installation force required to properly install the hardware you are going to insert. Refer to the technical specifications provided by the hardware manufacturer for this insertion force.
2. Select the proper tools for this application and install them in the Upper and Lower Tool Holders.
1. Have your Supervisor use their access code to set the Conductive/Non- Conductive mode to the Conductive position.

Setting the machine

1. Turn the Main Disconnect Switch to the On position.
2. Start the machine by pressing the On Switch. The green On light in the switch will turn on and the motor will start.
3. Verify Run Mode is selected.
4. Adjust the Ram up travel control to about 50% up the scale.
5. Adjust the Force to the fastener/part required force specification.

Checking the up travel & insertion

1. Keep your hands away from the tooling area. **Without** positioning the hardware or workpiece for insertion, depress the Down Footswitch and complete one stroke of the machine.
2. Check the position where the Upper Tool stopped. Is it adequate to permit the workpiece to be positioned easily while fasteners are installed? If not, adjust the Ram Up travel control accordingly. If an adjustment is necessary, check the new setting by cycling the machine again.
3. Keep your hands away from the tooling area. Insert the first piece of hardware into the workpiece.

Conductive mode set-up procedure (continued)

4. Examine the insertion. Is the hardware properly seated? Is the work piece deformed? Adjust the insertion force accordingly and insert another fastener.
5. Once the hardware is properly inserted, start the production run.



- Experienced personnel must test the Safety System at the beginning of each work shift. See the Safety System Test in this section of this manual.



Never attempt to test or demonstrate this machine's Safety System by placing any portion of your hand or body between the Upper and Lower tools. Always use the test procedure outlined in Step 3 of this manual.



Eye protection must be worn when operating this machine

Non-conductive mode set-up procedure



This procedure assumes that you are thoroughly familiar with this machine's controls as described in the first part of this section. If you are **not** familiar with these controls, **STOP**. Return to the beginning of this section and review any controls you are not thoroughly familiar with **before** continuing. If you have any questions, contact your Haeger Representative.



Depending on the ambient shop temperature, you may need to warm up your Haeger Hardware Insertion Machine before beginning any operations. To do this, turn it on and let it run for about ten minutes.

Getting started – Before you turn on the machine

1. Determine the installation force that you will need to properly install the hardware you are going to insert. Refer to the technical specifications provided by the hardware manufacturer for this insertion force.
2. Select the proper tools for this application and install them in the Upper and Lower Tool Holders.
3. Have your Supervisor use their access code to set the Conductive/Non- Conductive mode to the Non- Conductive position.

Setting the machine

1. Turn the Main Disconnect Switch to the *On* position.
2. Start the machine by pressing the On Switch. The green *On* light in the switch will turn on and the motor will start.
3. Verify Run Mode is selected.
4. Adjust the Ram up travel control to about 50% up the scale.
5. Adjust the Force to the fastener/part required force specification.

Checking the up travel & insertion

1. Keep your hands away from the tooling area. Without positioning the hardware or work piece for insertion, depress the Down Footswitch and complete one stroke of the machine.



Never leave your foot on or above the Down Footswitch after you have completed a cycle of the machine. Remove it from the Down Footswitch. Keep your feet away from the Down Footswitch until your hands are clear of the tooling area.

Non-conductive mode set-up procedure (continued)

2. Keep your hands away from the tooling area. Without positioning the hardware or work piece for insertion, depress the Down Footswitch. The Upper Tool Holder will move down, the Upper and Lower Tools will contact and stop. Release the Down Footswitch. Depress the Down Footswitch a second time. The machine will immediately apply the force to the Lower Tool, and the Upper Tool will return to the Up position
3. Check the position where the Upper Tool stopped. Is it adequate to permit the work piece to be positioned easily while fasteners are installed? If not, adjust the Ram Up travel control accordingly. If an adjustment is necessary, check the new setting by cycling the machine again.
4. Keep your hands away from the tooling area. Insert the first piece of hardware into the work piece.
5. Examine the insertion. Is the hardware properly seated? Is the work piece deformed? Adjust the insertion force accordingly and insert another fastener.
6. Once the hardware is properly inserted, start the production run.



- Experienced personnel must test the Safety System at the beginning of each work shift. See the Safety System Test in this section of this manual.
- **NEVER** press the Down Footswitch a second time in Non-Conductive Mode when your hands are in the tooling area.
- Never leave your foot on or above the Down Footswitch after you have completed a cycle of the machine. Remove it from the Down Footswitch. Keep your feet away from the Down Footswitch until your hands are clear of the tooling area.



Never attempt to test or demonstrate this machine's Safety System by placing any portion of your hand or body between the Upper and Lower tools. Always use the test procedure outlined in Step 3 of this manual.



Eye protection must be worn when operating this machine

SECTION 3 – HAEGER SAFETY SYSTEM

Safety precautions and warnings



Never

Operate this Haeger Hardware Insertion Machine without proper instructions. Read and thoroughly understand this manual before attempting to operate this machine.



Never

Tamper with any part of this machine's electrical system unless you are a trained electrician and thoroughly understand this machine's electrical schematic.



Never

Operate this machine while wearing any metal objects (i.e., rings, watches, bracelets, etc.) that may come into contact with the *Upper Tool*, *Lower Tool* or work piece.



Never

Attempt to test or demonstrate this machine's Safety System by placing any portion of your hand or body between the Upper and Lower tools. Always use the test procedure outlined in Section 4 of this manual.



Never

Exceed the maximum force of 9,000 pounds on the J- Frame and the *Square Tipped Tool Holder*.



Never

Attempt to run any irregular shaped sheet metal part that could contact the *Upper* and *Lower Tools* **before** these tools insert the fastener into the part. This applies to both the *Conductive* and *Non- Conductive Modes* of operation.



Never

Press the *Down Footswitch* a second time in the *Non-Conductive Mode* when your hands are in the area of the tooling.



Never

Operate this Machine without wearing the proper eye protection



Eye protection must be worn when operating this machine



The Safety System's heavy duty retractable electrical cord is very durable; however caution should be taken when working close to the edge of deep boxes or cans. Operating with the Safety System's electrical cord too close to sharp metal edges may damage the cord.



Lubricate the *Upper Tool Holder* with a small amount of lithium (white) grease. Any other lubricant may interfere with the Safety System's operation and will void your machine warrant

Safety system description

The Haeger Hardware Insertion Machine is equipped with a unique, reliable and patented *Safety System*.

Conductive Mode


When the Safety System detects a non- conductive material between the Upper and Lower Tools, the Upper Tool's downward motion reverses immediately and returns to its Up position.

Non-conductive mode

The Upper Tool's downward motion stops when **any** material is placed between the Upper and Lower Tools. If the Down Footswitch is depressed a second time after the Upper Tool has stopped, the machine continues the hardware insertion cycle. It applies the machine's set down force to the material. The Upper Tool then returns to its Up position.

How the safety system works

In both Conductive and Non-Conductive modes, the Safety System relies on the *Safety Switch* inside the *Cylinder Adapter*. The *Upper Tool Holder Retainer Screw* secures the Upper Tool Holder to the *Cylinder Rod*. There is a black serrated knob on this Retainer Screw. It enables the Upper Tool Holder to move up on the Cylinder Adapter .25 in./6.4 mm. To move up, the Upper Tool Holder must overcome the light force of the *Continuity Springs*.



The Safety Switch is inside the Upper Tool Holder.

How the safety system works (continued)



- Do not tamper with any part of the Safety System. The Haeger Hardware Insertion Machine will not operate properly if any part of the Safety System is removed or damaged.
- The heavy-duty, retractable Safety Electrical Cord is very durable, but caution should be taken when working close to the edges of deep cans. Operating with the Safety System Electrical cord too close to sharp metal edges may cut or shear the cord off.
- Test the Safety System every day **before** you use the machine. See the Safety System Test in this section of this manual.



- Never test or demonstrate the Safety System by placing any portion of your body between the Upper and Lower Tools.
- When operating the machine in the Non-Conductive Mode, be very careful. Do not press the Down Footswitch a second time with any portion of your body near the tooling.



- Always wear the proper eye protection when operating this Machine.

When the *Upper Tool Holder* moves up .015 in./4 mm to .02 in./5 mm, the *Safety Switch Actuation Screw* actuates the Safety Switch which is mounted in the end of the machine's *Cylinder Adapter*, opening its contacts. When the Safety Switch contacts are opened, the Upper Tool either returns to the Up position if the machine is in *Conductive mode*, or it stops if it is in *Non-Conductive mode*.


In operation, when the Safety Switch is actuated in *Conductive Mode* and a non-conductive material is between the Upper and Lower Tools, the Upper Tool Holder's downward motion is reversed immediately and returns to its Up position. If the Safety Switch is actuated and a conductive material is between the Upper and Lower Tools, the machine will continue the hardware insertion cycle. The machine will apply the set down force to the conductive material between the Upper and Lower Tools and then return to its Up position.

When the Safety Switch is actuated in the *Non-Conductive Mode* and **any** material is between the Upper and Lower Tools, the Upper Tool Holder stops. At this point, if the Down Footswitch is depressed a second time, the machine will continue the hardware insertion cycle by applying the set down force to the material between the Upper and Lower Tools and then return to its Up position.

Lockout-Tagout


Lockout-tagout (LOTO) or **lock and tag** is a safety procedure which is used ensure that malfunctioning machines are properly shut off and not started up again prior to the completion of maintenance or servicing work. It requires that hazardous power sources be "isolated and rendered inoperative" before any repair procedure is started. "Lock and tag" works in conjunction with a *lock* usually locking the device or the power source and placing it in such a position that no hazardous power sources can be turned on. The procedure requires that a *tag* be affixed to the locked device indicating that it should not be turned on.



Lockout-Tagout procedure:




Access Level:

- Machine User does not have access to Shut Down the machine.



2. Password: User passwords are established during User Setup in the  Admin on the main screen then touch on Manage Users . To changing user's password, touch on



Lockout-Tagout (continued)



Lockout-Tagout (continued)



- Main Power Switch
- Rotate to OFF Position



- Use Finger -- push to expose holes and insert lock



- Lockout



- Tagout



DANGER:


- THIS TAG & LOCK TO BE REMOVED ONLY BY PERSON SHOWN ON BACK!
- DO NOT REMOVE THIS TAG!

Fire Safety Equipment

Haeger systems do not produce thermal, biological, fire or radiation hazards etc., however if in the event of a fire, having a Multi-Class rated fire extinguisher within a reasonable distance of the machine operator(s) is a sound safety practice and is recommended. Your fire extinguisher (or fire extinguishers) should be able to extinguish fires involving ordinary combustable materials, flammable/combustible liquids and energized electrical equipment.

The following is an example of a fire extinguisher with a Multi-Class rating.

Multi-Class Rated Fire Extinguisher



Fire Safety Note: All fires are grouped into classes, according to the type of materials that are burning. The classes of fire for the UK, Europe, Asia etc., are different to those used in the USA and Australia so remember to always read labels carefully and consult a trained fire professional.

Safety Awareness & Residual Risks

Introduction

This section contains two sets of principles that must be followed to assure maximum safety when operating your Haeger Hardware Insertion Machine. The 1st explains behavior and conduct in an effort to avoid or prevent injury. The 2nd principle describes the residual risks that are inherent in the operation of the Hardware Insertion Machine. These are situations or physical aspects of the machine that may present a potential danger to the operator or machine maintenance person, but would compromise the capabilities of the machine if changed. Therefore, they are pointed out as a precaution the operator and trained maintenance person must be aware of when using the machine.

1. Situations and Actions to Avoid

The Haeger safety system ensures up to a certain level the discrimination between human body and part to be processed. Despite this safety system the safety of the operator still depends from operator appropriate behavior and respect of the procedure. Human behavior is still important in non-conductive mode. The safety system may be partly inefficient when machine is used in conductive mode (contact of a simple metallic ring on the operator's finger with upper tool may validate the down stroke). In short, don't get distracted while operating or maintaining the machine, **always be aware** of what you are doing!

2. Residual Safety Risks


Your Haeger Hardware Insertion Machine is engineered to minimize machine components and operating procedures that may compromise operator safety. However, in order to maintain some machine operations and functionality, certain compromises are required. The following table documents some of these residual hazards. By making the operator aware of the potential risks, we hope to ensure maximum safety in the operation of this machine.




Attention: The photos in the following table illustrate situations that must be avoided when operating your machine.

Safety Awareness (Residual Safety Risks, continued)

Operator Safety Awareness & Residual Risks



1.



2.



Risk of crushing: A high risk crushing hazard is created by the Upper Tool and Lower Tooling.




Safety of the operator in **non-conductive** access operation must remain accessible **only** to trained and authorized personnel that are experienced in appropriate machinery operating conduct.



When operating this machine while wearing any metal objects (i.e., rings, watches, bracelets, etc.) that may come into contact with the *Upper Tool*, *Lower Tool* or work piece.

Safety Awareness (Residual Safety Risks, continued)

3.



Risk of pinching: A medium risk pinching hazard is created by the Multi-Shuttle moves back and forward exchanging lower tools.

4.



Risk of pinching: A medium risk pinching hazard is created by the Lower Tool rotates for the next station.

Safety Awareness (Residual Safety Risks, continued)

Maintenance Safety Awareness & Residual Risks


5.



Risk of Electrical Shock: A high risk electrical shock while working on the **RIGHT HALF** of the electrical cabinet.

See Section 7 Electrical Cabinet Assembly to identify High and Low voltage components.

6.



Risk of Electrical Shock: A high risk electrical shock while working here.



High Voltage hazard is **ALWAYS** present in this location, until **INCOMING (MAIN)** power is shut OFF.

Safety System Tests

Step 1: Safety switch test procedure



Experienced personnel must test the Safety System at the beginning of each work shift. See the Safety System Test in this section of this manual.



Depending on the ambient shop temperature, you may need to warm up your Haeger Hardware Insertion Machine before beginning any operations. To do this, turn it on and let it run for about ten minutes.

1. Turn the *Main Disconnect Switch* to the *On* position. The Main Disconnect Switch is located on the upper left and right side of the cylinder cover of the machine.
2. Start the machine by pressing the *On* Switch on the control Panel. The green light in the switch will be illuminated and the motor will start. If the machine doesn't turn on, twist the *Off/E-Stop* Switch(s) clockwise until it pops out and try pressing the *On* Switch again. Using the touch screen controls, select the *Conductive* operation.



Except for the *Down Footswitch* and the *Off/E-Stop Switch*, all the other operating controls referred to in the rest of this procedure are on the Touch Screen Panel. The Touch Screen Panel is located on the front of the machine cover.

3. Set the machine to Run mode by touching the circle next to the word Run on the screen. Set the Up Travel distance to 40% by touching the box containing the Up Travel value and then choosing 30 from the entry screen. You can also use the +/- buttons.
4. Keep your hands away from the Tool Holder area. Use the Footswitches to lower or raise the Upper Tool Holder until it is about 4 in. /100 mm above the Lower Tool Holder. Remove your foot from the Footswitches and keep your feet away from it.
5. Carefully grasp the sides of the Upper Tool Holder and push it upwards. This upward movement should actuate the Safety Switch and the Upper Tool Holder should move up. The movement will continue until the Up timer (set by the Up Travel % number you enter) has timed out. Remove your hand from the Upper Tool Holder as soon as the movement starts.
6. If the Upper Tool Holder moves up, the Safety System Switch is operating. Go to **Step 2, "Conductive Mode Test Procedure."**
7. If the Upper Tool Holder does not move up, **the Safety System has failed!**



- a. Immediately turn the machine off by depressing the *E-Stop* button and turning the Main Disconnect Switch to the *Off* position. Contact your Supervisor. The machine's Main Disconnect

Step 1: Safety switch test procedure (continued)

Switch must be locked in the *Off* position until repairs are begun and follow Lock-out/Tag-out procedures. Do not operate this machine until qualified personnel have repaired the machine and the Safety System Switch has been properly tested.



There are three (3) Steps in this testing procedure.

Do not skip or ignore any of them!

Step 2: conductive mode test



Never attempt to test or demonstrate this machine's Safety System by placing any portion of your hand or body between the Upper and Lower tools. Always use the test procedure outlined in Step 3 of this manual.



NEVER Operate this Machine without the proper tooling installed. If no material and fastener is used, you must use two flat anvils.

1. Following the Upper and Lower Tool Installation instructions, install the 1 in. / 25 mm Flat Anvils in both the Upper Tool Holder and the Lower Tool Holder.
2. If you have just completed Step 1: "Safety Switch Test Procedure,"
 - a. The machine is *On* and the green light in the *On* Switch is still illuminated. If not, return to Step 1 and restart the machine by following Instructions 1 and 2.
 - b. The Conductive/Non-Conductive selection is in the *Conductive* display. If not, select the *Conductive*.
3. Set the machine to Setup mode by touching the circle next to the word Setup on the screen
4. Change the machine's force to 3,000 lb (13KN) by touching the box next to Force, entering 3000 and touching the Enter button. You can also use the +/- buttons.
5. Raise the Upper Tool Holder about 4 in./100 mm by depressing the Up Footswitch.
6. Keep your hands away from the tooling area.
 - a. Depress the *Down* Footswitch. The Upper Tool Holder should move down, the Anvils will contact, the machine will apply the set force to the Lower Anvil and the Upper Tool Holder will return to the Up position.
 - b. If this machine completes the above sequence correctly, go to Instruction 8.
 - c. If the machine does not complete the above sequence correctly, check the screen settings. If they are not correct, reset them and repeat the test. If the machine performs **correctly**, go to Instruction 8.
7. If the machine **does not** complete the above sequence correctly, there is a failure in the machine's control circuit.



- a. *Trained personnel must correct it. Immediately turn the machine off by pressing the red Off Switch and turning the Main Disconnect Switch to the Off position. The machine's Main Disconnect Switch must be locked in the Off position until repairs are begun and follow Lock-out/Tag-out procedures. Do not operate this machine until qualified personnel have repaired the machine and the Conductive Mode has been properly tested.*

Step 2 conductive mode test (continued)

8. Next Place a small non-conductive material (e.g., plastic or paper) on top of the Lower Anvil, making sure the object completely covers the top of the Anvil. Keep your hands away from the tooling area. Depress and hold the Down Footswitch. The Upper Tool Holder should move down, the Anvil will contact the non-conductive object and, **without applying the pre-set force**, return to the Up position.
 - a. This part of Safety System is operating correctly in Conductive Mode. After confirming that **no force** was applied to the non-conductive object, go to **Step 3, "Non-Conductive Mode Test Procedure."**
9. If the force was applied to the non- conductive object, **the Safety System has failed!**



- a. Immediately turn the machine Off by pressing the red *Off* Switch and turning the Main Disconnect Switch to the *Off* position. The machine's Main Disconnect Switch must be locked in the *Off* position until repairs are begun and follow Lock-out/Tag-out procedures. Do not operate this machine until qualified personnel have repaired the machine and the Conductive Mode has been properly tested.

Step 3: Non-conductive mode test



There are three (3) Steps in this testing procedure.

Do not skip or ignore any of them!

2. If you have just completed Step 2:
 - a. The machine is *On* and the green light in the *On* Switch is still illuminated. If not, return to Step 1 *Safety switch test procedure* and restart the machine by following Instruction in *Steps 1 and 2*.
 - b. The Conductive/Non-Conductive mode is displayed in the *Conductive selection*. Select *Non-conductive* from the touch screen display.
 - c. Verify *Auto Run* is selected.
 - d. The machine's Force has been set to deliver 3,000 lb/13 Kn. If this has been changed, repeat the instructions in Step 2, Instruction 4.
 - e. Verify the 1 in./25 mm Flat Anvils are installed in both the Upper and Lower Tool Holders.
3. Turn the Conductive/Non-Conductive Switch to the Non-Conductive position.
4. Keep your hands away from the tooling area. Depress the Down Footswitch. The Upper Tool Holder should move down, the flat Anvils will contact, and the Upper Tool Holder should **stop immediately**. If this machine completes the above sequence correctly, go to Instruction 4.



When operating this Hardware Insertion Machine in the Non-Conductive Mode, be very careful! Do not depress the Down Footswitch a second time after the Upper Tool Holder has stopped on the down stroke with any part of your body near the tooling area.


- a. If the machine **does not** complete the above sequence correctly, check the touch screen settings. If they are not correct, reset them and repeat the test. If the machine performs correctly, go to Instruction 3.
- b. If the machine **does not** complete the above sequence correctly, there is a **failure** in the machine's control circuit and it must be corrected by qualified personnel. Immediately turning the machine *Off* by pressing the red *Off* Switch and turn the Main Disconnect Switch to the Off position. The machine's Main Disconnect Switch must be locked in the *Off* position until repairs are begun. Do not operate this machine until qualified personnel have repaired the machine and the Non-Conductive Mode has been properly tested.



4. Remove your foot from the Foot pedal switch box.

Step 3: Non-conductive mode (continued)

5. Carefully grasp the sides of the Upper Tool Holder and raise it until a positive stop position is reached. With a calibrated measuring instrument (Digital calipers are best), measure the vertical distance between the upper and lower Anvils. If this measurement **is at least a minimum of .060" in. /1.52 mm**, go to Instruction 5.



- a. If this dimension **is less than .060" in. /1.52 mm**, the **Safety System has failed!**

Immediately turn the machine off by pressing the red Off Switch and turning the Main Disconnect Switch to the *Off* position. The machine's Main Disconnect Switch must be locked in the *Off* position until repairs are begun and follow Lock-out/Tag-out procedures. Do not operate this machine until qualified personnel have repaired the machine and the Non-Conductive Mode has been properly tested.



6. Next keep your hands away from the tooling area. Depress the Down Foot pedal switch a second time. The machine should exert the pre-set 3,000 lb/13 Kn force to both upper and lower Anvils and then return to its Up position.



If this machine completes the above sequence correctly, the test of the Safety Switch and Safety System is complete and operating properly.

SECTION 4 – TOUCH SCREEN OPERATION (Step by Step Demo)


Window Touch-4e - Introduction

This section provides you, the operator, with all the information that you need to operate the Haeger 824 WindowTouch-3 safely and productively.

Make sure that you read and understand all of the descriptions, instructions and notes contained in this section. Heed all of the Warnings and Cautions in this manual.

Your **safety** and productivity depend on it.

Machine Controls




Control Panel



- Read and understand all Warnings and Cautions in this manual and follow the instructions for testing the Safety System in the Safety System section before attempting to operate this machine
- NEVER wear anything metallic that may come into contact with the Upper Tool, Lower Tool or work piece (watches, rings, bracelets, etc.).
- Never leave your foot on or above the Down foot switch after you have completed a cycle of the machine. Remove it from the Down foot switch. Keep your feet away from the Down foot switch until your hands are clear of the tooling area and you intend to lower or raise the Upper Tool Holder or insert hardware.
- **NEVER Operate this Machine without wearing the proper eye protection!**

Touch Screen Hierarchy Overview



User level security access

User level security access, each login account is assigned a security level by an administrator. When the machine is first powered *On* or operator change occurs, the user security level must be selected to access the Run or Start Production screen. **Access & permissions are as follows:**

	<u>Administrator</u>	<u>Advanced Administrator</u>	<u>Operator Level</u>	<u>Machine User</u>	<u>Haeger Technician</u>
 Main Screen					
Quick Run	Yes	Yes	Yes	--	Yes
Run	Yes	Yes	Yes	Yes	Yes
Programs	Yes	Yes	Yes	--	Yes
Admin	Yes	Yes	Yes	--	Yes
 Quick Run					
Setup Stations	Yes	Yes	Yes	--	Yes
 Run					
Run Programs	Yes	Yes	Yes	Yes	Yes
 Programs					
Filter	Yes	Yes	Yes	--	Yes
Select Programs	Yes	Yes	--	--	Yes
Create New Program	Yes	Yes	--	--	Yes
Edit Loaded Program	Yes	Yes	Yes	--	Yes
Preview Program	Yes	Yes	Yes	--	Yes
Start/Load Program	Yes	Yes	Yes	--	Yes
Edit Selected Program	Yes	Yes	--	--	Yes
Delete Program	Yes	Yes	--	--	Yes
 Admin					
Change User's Password	Yes	Yes	Yes	--	Yes
View/Manage Log Files	Yes	--	--	--	Yes
Change Application Config.	Yes	--	--	--	Yes
Open Touch Screen Config.	Yes	--	--	--	Yes
Machine Diagnostics	Yes	--	--	--	Yes
Add/Remove Users	Yes	--	--	--	Yes
Special Functions	Yes	--	--	--	Yes
 Exit					
Shut Down	Yes	Yes	Yes	--	Yes
Restart	Yes	Yes	Yes	--	Yes
Logoff	Yes	Yes	Yes	Yes	Yes
Exit App.	--	--	--	--	Yes



Quick Run Step by Step Demo

The 824 WindowTouch-4 Insertion Machine is equipped with a computer running InsertionLogic software. This computer controls most of the machine's settings and functions and is equipped with a touch screen. You will use the touch screen to enter information into the computer.

Using the touch screen


The touch screen is the main method of entering information into the software and controlling the computer. To use a button on the touch screen, press firmly on the center of the button.



1. Turn on the machine by turning the main disconnect switch to the ON position



Conductive Mode:


- Turn key to the Right.
-  Key is removable in this position and should **not** stay with the machine – key should be kept by a trained setup person or shop owner.





3. Push Machine ON Switch


The InsertionLogic banner screen will appear on the computer, signifying that the computer is starting up. Once the system environment is fully started, the Log In screen will be displayed.





1. Select User: This screen allows you to select from a list of users established in the  on the main screen then


touch on  to add/revoke a user.

 The Administrator, Advanced Operator, Operator, Machine User and Haeger Technician users come pre-set in the InsertionLogic software and cannot be deleted. It is recommended to use them as a template for adding users. For a quick reference on the differences between user and access levels, see **User level security access**, page 16 of this manual.




2. Password: User passwords are established during User Setup in the  on the main screen then

touch on  to changing user's password, touch on

 Change user's password




To program a Quick Run operation you will follow the easy programming wizard using the steps.



Input 1: Station


1. Station: Station **1** is a high volume, **Automatic** insertion station working in conjunction with Modular Automated Feed System (MAS).
Stations **2**, **3**, **4** are Manual tooling/Manual feed insertion stations.



Input 2: Material

2. Material:

- Aluminum
- Steel
- Stainless
- Copper




Input 3: Fastener


3. Fastener:

- Nut
- Standoff
- Stud/Pin
- Blind standoff

10.



11.




Input 4: Unit & Size

4. Unit & Size:

- Metric
- Unified

12.



Input 5: Insertion Values


Force (LBS)

5. Force (lbs): Is the amount of pounds of force that will be applied between the Upper and Lower Tools during the hardware insertion cycle. The force can range from 1,000 pounds (4.46KN) to 16,000 pounds (71.35 KN). The 3300 lbs value displayed is derived from a manufacturers table of values however it can be increased or

decreased by touching the **+** or **-** symbols on either side of the value shown.


Or touch on the value **3300** itself, to touch type a new value.

Check the specifications for your fastener to determine the appropriate force to use.




5. Dwell (Sec): The Dwell is the length of time that the force is applied between the Upper and Lower Tools. It can range from 0.0 seconds to 3.0 seconds. If you set the Dwell to 0.0 seconds, the Upper Tool will lower, apply the Force and immediately return to the Up position. If you set the Dwell value greater than 0.0 seconds, the Upper Tool will lower and continue applying the force for the length of time set here.

i An increased Dwell setting should be used when inserting fasteners into materials such as stainless steel.



5. Up Travel (%): Not Applicable here


The Up Travel value controls the Up position of the Upper Tool. This is the position the upper tool returns to after applying the force. The Up value is measured as a percentage of the total cylinder stroke. It will vary depending on the size of the Upper and Lower Tools. If the Up value is set to 0%, the Upper Tool will return to its minimum height after applying a force. Setting the Up value to 70-100% will cause the Upper Tool to return to the highest point possible.



6. Eject Time (Sec): The Air Eject Time controls the duration or the blow off time of the air blast which sends the fastener from your MAS 350 to the desired automatic tooling. Use the Eject Timer to adjust the duration of the air blast.

i If the fastener does not travel all the way to the tooling, increase air ejection time.

16.




Vibration (%)

6. Vibration (%): Vibration controls the MAS 350 bowl vibration speed. The bowl's vibration speed controls how fast the hardware travels up the spiral track of the feeder bowl to reach the Multi Module.

! The 50% value shown is a starting point only. Experiment with different values to achieve proper fastener line up at the Door/Gate of the MAS 350 bowl.

i Keep good notes for programming production runs later.

17.




Vibration Time (Sec)

6. Vibration Time (Sec): Vibration Time controls the duration of time of which your MAS 350 will continue to vibrate after a fastener has been ejected to the tooling. Use the vibration time to adjust the vibration of hardware in the bowl to keep a full track of hardware once the MAS 350 has stopped vibrating for the next eject command.

! The 2 (sec) value shown is a starting point only. Keep good notes for programming production runs later.


18.



Input 7: Quality Control
Tooling Protection System (TPS)

7. TPS: The Tooling Protection System (TPS) is designed to protect both the tooling and the work piece from damage. The TPS can be activated by touching the TPS ON/OFF button.

19.




Fastener Length

7. Fastener Length: This will instruct the machine to perform length verification of a fastener when the fastener contacts the lower tool. The Fastener Length can be activated or deactivated by touching the Fastener Length ON/OFF button.

i This feature is particularly helpful with the insertion of studs, assuring the correct length is being inserted.

i This feature is not active when the "Tooling" selection is set to Manual or Bottom Feed modes.

20.




Fastener Detection

7. Fastener Detection: This will instruct the machine to perform detection of a fastener at the fastener pickup point of the Shuttle Tooling jaws. The Fastener Detection can be activated or deactivated by touching the Fastener Length ON/OFF button.

i This feature is not active when the "Tooling" selection is set to Manual or Bottom Feed modes.

21.




Input: Status
Clamp

Turret Insertion System (TIS): This feature allows for the operator to unlock



the TIS allowing it to rotate for the installation and alignment of the lower tools.


22.



Vacuum

Vacuum: This feature allows for the operator to switch ON or OFF the vacuum system during the use of automatic tooling with upper vacuum anvil.

23.




Tooling

Tooling: This feature allows the operator to select the type of tooling to run in the selected station.


Tooling Options are: Shuttle, Manual and Bottom Feed

24.





Modular Auto Feed System (MAS)


Modular Auto Feed System (MAS): This feature allows the operator to either run the MAS 350 at a continuous vibration or an intermittent vibration. Continuous vibration is commonly used when running the bowl out of hardware for a tooling change or for those small quantity hardware runs. Intermittent vibration is most commonly used for normal insertion applications where you have good quantity of hardware that will keep your multi module full at all times.





Eject Fastener: This feature allows the operator to eject a fastener from the MAS bowl to the automatic tooling system.




Setup Stroke : This feature allows the operator to create a first stroke setup. This first stroke setup feature must be completed for each of the tooling stations used in the insertion quick run program, to record all applicable values required for Automation. Such as the Shuttle Set Point, Tip Detection, Fastener Length, and Fastener Detection.



Setup Stroke Step 1 - Station 1 : Upper tool will lower and record the information applicable to the fastener being inserted.

 Upper tool in motion

28.




Setup Stroke Step 2 - Station 1:
Fastener Pickup Point, vacuum detection, Length and Tooling Protection have been detected and recorded.



! If one or both of these values are set to OFF, Setup Stroke will **NOT** detect those that are OFF.

29.




Setup Stroke Step 3 - Station 1:
Fastener insertion complete.



! Stations are Manual tooling/Manual feed insertion stations, thus Setup Stroke is not applicable.

30.



Upper tool in downward motion

! If you remove your foot from the Down Footswitch, the Upper Tool Holder will stop. If you depress the Down Footswitch again, the downward motion will start again.

Station 1: Repeat depressing foot switch until run is completed.

31.



Touch on Close to exit Quick Run




Programs Setup Step by Step Demo

Make sure that you read and understand all of the descriptions, instructions and notes contained in this section. Heed all of the Warnings and Cautions in this manual.

Your **safety** and productivity depend on it.

One of the most useful features of InsertionLogic is the ability to store and retrieve programs. When you save a program, you are saving all the setup values (for instance: Force, Dwell, Up Position, TPS, Fastener Detection, Fastener Length, and Teach sequences).

Programs can also contain images which illustrate where fasteners are to be inserted.

This section provides you, the operator, with the information that you need to add a  Program and operate the Haeger 824 WindowTouch-4 safely and productively.

Machine Controls



Touch Screen

Emergency Stop

Foot Switches

Control Panel



Emergency Stop

Machine OFF Switch

Conductive / Non-conductive Switch

USB Port

Machine ON Switch



- Read and understand all Warnings and Cautions in this manual and follow the instructions for testing the Safety System in the Safety System section before attempting to operate this machine
- NEVER wear anything metallic that may come into contact with the Upper Tool, Lower Tool or work piece (watches, rings, bracelets, etc.).
- Never leave your foot on or above the Down foot switch after you have completed a cycle of the machine. Remove it from the Down foot switch. Keep your feet away from the Down foot switch until your hands are clear of the tooling area and you intend to lower or raise the Upper Tool Holder or insert hardware.
- **NEVER Operate this Machine without wearing the proper eye protection!**




32. Turn on the machine by turning the main disconnect switch to the ON position

33.



Conductive Mode:

- Turn key to the Right.
-  Key is removable in this position and should **not** stay with the machine – key should be kept by a trained setup person or shop owner.


34.





Push Machine ON Switch


The InsertionLogic banner screen will appear on the computer, signifying that the computer is starting up. Once the system environment is fully started, the Log In screen will be displayed.





1. Select User: This screen allows you to select from a list of users established in the  on the main screen then

touch on Manage Users  to add/remove a user.

 The Administrator, Advanced Operator, Operator, Machine User and Haeger Technician users come pre-set in the InsertionLogic software and cannot be deleted. It is recommended to use them as a template for adding users. For a quick reference on the differences between user and access levels, see **User level security access**, page 16 of this manual.




2. Password: User passwords are established during User Setup in the  on the main screen then


touch on Manage Users  . To changing user's password, touch on



To Program a production operation you will follow the easy programming wizard using the steps.




37. Programs



38. Create New Program

3. Create New: One of the most useful features of InsertionLogic is the ability to store and retrieve programs. When you save a program, you are saving all the setup values (for instance: Force, Dwell, Up Position, TPS, Fastener Detection, Fastener Length, and Teach sequences). Programs can also contain images which illustrate where fasteners are to be inserted.


! Programs are stored on the machine hard drive.



39. Program Name

1.1 Program Name: For this example we chose Part ID: "Program Demo Plate 1"







1.2 New Customer: Haeger, Inc.



If customer has already been entered, choose "Existing" to see the list for selection.



1.3 Program Notes: 4 Fastener Demo




2. Fastener Differentiation:



How many different types of fasteners (1 to 4) are being inserted into this part?



Program Wizard (Automatic or Manual, Station 1 of 4)



43.

1. Preset:


Library

1. Preset:

- **Wizard Tab:** Typically used to guide you through setup
- **Search Fastener Tab:** Takes you to your list of saved fastener types in both Global and Local databases
- **Add New Fastener Tab:** Gives the local user the ability to add their own fasteners

LIBRARY:

- **Global:** Includes Pre-loaded fasteners from different manufactures in software database.
- **Local:** User added fasteners to their machine via the ADD NEW FASTENER tab on this screen.




44.

Part Material

1. Part Material:

- Aluminum
- Steel
- Stainless
- Copper



45.


2. Fastener:

Manufacturer


2. Manufacturer:

- Captive
- Kerb Konus
- PEM
- PSM

* We will be selecting a **Steel Captive Standoff CFSO-632-10** for our Automatic Insertion fastener 1 of 4.




type




3. Size

Unit of Measure




Fastener Length

Part Identification




6. Select Tooling Type:

i Shuttle tool is typically setup in station 1 (automatic station), which works in combination with the MAS bowl.



2.7 Tooling:

2.8 Tooling Information:



Repeat Wizard to program STATION


2

* This time, let's select a **Steel Captive Nut C-632-2** for our fastener 2 of 4.

1. Preset Library:

- **Global:** Includes Pre-loaded fasteners from different manufactures in software database.
- **Local:** User added fasteners to their machine via the ADD NEW FASTENER tab on this screen.

52.




1. Part Material:

- Aluminum
- Steel
- Stainless
- Copper

2. Manufacturer:

- Captive
- Kerb Konus
- PEM
- PSM


53.



3. Size:


- Metric
- Unified
- Size ID #

54.




4. Length:

5. Part #:




6. Select Tooling Type:

Stations 2 through 4 are manually operated stations.



2.7 Tooling:

2.8 Tooling Information:




Program Wizard (Manual, Station 3 of 4)

Repeat Wizard to program STATION 3

* This time, let's select a **Steel Captive Stud CH-632-6** for our fastener 3 of 4.

1. Preset Library:

- **Global:** Includes Pre-loaded fasteners from different manufactures in software database.
- **Local:** User added fasteners to their machine via the ADD NEW FASTENER tab on this screen




58.

Repeat Steps: to program STATION

3

1. Preset
2. Fastener
3. Size
4. Length
5. Fastener
6. Select Tooling Typer


i Stations 2 through 4 are manually operated stations.



59.

2.7 Tooling:

2.8 Tooling Information:



60.

Program Wizard (Manual, Station 4 of 4)

Let's Speed up the programming steps by using **SEARCH FASTENER** in lieu of the

4

wizard to program STATION

* This time, let's select a **Steel Captive Nut TR-SL-440-1** for our fastener 4 of 4.

1. Preset Library:

- **Global:** Includes Pre-loaded fasteners from different manufactures in software database.
- **Local:** User added fasteners to their machine via the ADD NEW FASTENER tab on this screen


61.



1. Fastener Name Filter: Touch typing in 440 returns all hardware with 440 in the description.


i To go directly to the desired fastener, touch type in the part TR-SL-440-1.

62.



2. Select Fastener:


63.



3. Material:


4. Select Tooling Type:

i Stations 2 through 4 are manually operated stations.




2.7 Tooling:

2.8 Tooling Information:




Add Insertion Group


2. Amount: This screen takes you back to **1** STATION to enter the **AMOUNT** or **NUMBER** of fasteners to be inserted for this station.



2. Amount of Insertions in Group





3. Image: This icon associates a part image with the insertion group.



1. Location: Images can be selected from two different locations:

- **USB:** Typically used to pull in images from a camera or flash drive. For this example, we took a picture of the part and loaded the image by selecting USB.
- **Local HDD:** Images that reside on the machines local hard drive are selected from here.





70. Select Insertion Points

1. Select Points: Identify Group 1 Insertion Points.



Immediately after touching and locating **a point** on the screen, you have an opportunity to move the point directly over the insertion hole. Touch on or touch and hold on the appropriate arrow



to center insertion point over the desired insertion hole.




If you want to move a point, for example, insertion point 2 of 4, you must delete the last 2 points (3 & 4) using the




button, before you can reposition point 2.




71.




72.




2. Amount: This screen takes you back to STATION **2** to enter the **AMOUNT** or **NUMBER** of fasteners to be inserted for this station.





2. Amount of Insertions in Group




3. Image: This icon associates a part image with the insertion group.



1. **Location:**  Images can be selected from two different locations:
 - **Pre-Used:** Saved images previously used.




2. **Select Points:** Identify Group 2 Insertion Points.

 **Immediately** after touching and locating a **point** on the screen, you have an opportunity to move the point directly over the insertion hole. Touch on or touch and hold on the appropriate arrow





to center insertion point over the desired insertion hole.

 If you want to move a point, for example, insertion point 2 of 3, you must delete the last point (3) using the




button, before you can reposition point 2.






2. Amount: This screen takes you back to STATION **3** to enter the **AMOUNT** or **NUMBER** of fasteners to be inserted for this station.



2. Amount of Insertions in Group




- Select a part image for hardware insertion
- Touch on IMAGE




- **Pre-Used:** Saved images previously used.


- Touch on IMAGE




17-00001-C




2. Amount: This screen takes you back to STATION **4** to enter the **AMOUNT** or **NUMBER** of fasteners to be inserted for this station.



2. Amount of Insertions in Group







3. Image: This icon associates a part image with the insertion group.



3. Location:  Images can be selected from two different locations:


➤ **Pre-Used:** Saved images previously used.






94. Insertion Group Program Correction Example (Station 3)

- Program Review
- **OOPS!** Station **3** should have 3 fasteners -- we missed an insertion and have to go back and add it!




95. Quickly Double Touch on the picture to re-select image.




96. Touch on IMAGE


97.







98.



99.







- **i YES:** Saves and then RUNS the program.
- **i NO:** Saves program and takes you back to the Main Screen.
- **i CANCEL:** DOES NOT Save the program and takes you back to Program Wizard.






Run Program Step by Step Demo

Make sure that you read and understand all of the descriptions, instructions and notes contained in this section. Heed all of the Warnings and Cautions in this manual.

Your **safety** and productivity depend on it.

One of the most useful features of InsertionLogic is the ability to store and retrieve programs. When you save a program, you are saving all the setup values (for instance: Force, Dwell, Up Position, TPS, Fastener Detection, Fastener Length, and Teach sequences).

Programs can also contain images which illustrate where fasteners are to be inserted.

This section provides you, the operator, with the information that you need to add a  Program and operate the Haeger 824 WindowTouch-4 safely and productively.

Machine Controls



Touch Screen

Emergency Stop

Foot Switches

Control Panel



USB Port

Emergency Stop

Conductive / Non-conductive Switch

Machine OFF Switch Machine ON Switch



- Read and understand all Warnings and Cautions in this manual and follow the instructions for testing the Safety System in the Safety System section before attempting to operate this machine
- NEVER wear anything metallic that may come into contact with the Upper Tool, Lower Tool or work piece (watches, rings, bracelets, etc.).
- Never leave your foot on or above the Down foot switch after you have completed a cycle of the machine. Remove it from the Down foot switch. Keep your feet away from the Down foot switch until your hands are clear of the tooling area and you intend to lower or raise the Upper Tool Holder or insert hardware.
- **NEVER Operate this Machine without wearing the proper eye protection!**




105. Turn on the machine by turning the main disconnect switch to the ON position



106.



Conductive Mode:



- Turn key to the Right.
-  Key is removable in this position and should **not** stay with the machine – key should be kept by a trained setup person or shop owner.





107. Push Machine ON Switch

The InsertionLogic banner screen will appear on the computer, signifying that the computer is starting up. Once the system environment is fully started, the Log In screen will be displayed.


Access Level Reminder:


	<u>Administrator</u>	<u>Advanced Administrator</u>	<u>Operator Level</u>	<u>Machine User</u>	<u>Haeger Technician</u>
 Run					
Run Programs	Yes	Yes	Yes	Yes	Yes
 Programs					
Filter	Yes	Yes	Yes	--	Yes
Select Programs	Yes	Yes	--	--	Yes
Create New Program	Yes	Yes	--	--	Yes
Edit Loaded Program	Yes	Yes	Yes	--	Yes
Preview Program	Yes	Yes	Yes	--	Yes
Start/Load Program	Yes	Yes	Yes	--	Yes
Edit Selected Program	Yes	Yes	--	--	Yes
Delete Program	Yes	Yes	--	--	Yes

! Access Level Reminder:
Machine User does not have access to **LOAD** a Program. Admin/Operator must Load it first – Then the Machine User can **RUN** it.


- Administrator/Operator
 - o Log-in,  Load Program, Close Program, Log-out
- Machine User
 - o Log-in,  RUN previously Loaded Program





1. Select User: This screen allows you to select from a list of users established in the  Admin on the main screen then

touch on Manage Users  to add/remove a user.


i The Administrator, Advanced Operator, Operator, Machine User and Haeger Technician users come pre-set in the InsertionLogic software and cannot be deleted. It is recommended to use them as a template for adding users. For a quick reference on the differences between user and access levels, see **User level security access**, page 16 of this manual.




Password: User passwords are established during User Setup in the  Admin on the main screen then touch on Manage Users  . To changing user's password, touch on  Change user's password



Production Run Overview



Batch Size
Parts Completed
MAS Vibration (%)
MAS
Preview



Production Run Overview

Program Action

- Batch Size:** Is how many parts you must complete. Batch quantities can be increased or decreased by touching the **+** or **-** symbols on either side of the value shown.


Or touch on the value **0.0** itself, to touch type a new value.

- Parts Completed:** A running count of completed parts within a batch.
- MAS Vibration (%):** This feature allows the operator to increase or decrease the vibration intensity of the MAS 350 bowl.




- MAS:** Touch 1 to manually vibrate the fasteners up to the MAS doorway ready to for ejection. An example of use -- filling the MAS bowl for the first time.

! Verify the Program selected matches the part for insertion and hardware in Stations 1, 2, 3 & 4. Touch on PREVIEW to see Tooling, hardware insertions per part and a picture of the part.




113. Station 1 Insertion – Start Production



114. Turn TIS to Station 1

! TIS is now UNLOCKED, allowing you to turn it to Station 1. When in the correct position, the machine will automatically lock the TIS.



115. Setup Stroke

SETUP STROKE REQUIRED

i Eject Fastener: This feature allows the operator to eject a fastener from the MAS bowl to the automatic tooling system.


! **Setup Stroke:** Saves all the setup values such as Fastener pick up point, vacuum detection, length and tooling test.



Upper tool in motion



Upper tool in motion




Adjusting Insertion Values

ADJUSTING INSERTION VALUES


i YES: Insertion was completed successfully and ready to move on to next insertion point

i NO: Opens the Adjust Fastener Window. Change Insertion and/or MAS values to achieve desired insertion production results.



119.


i Fastener Data is displayed as programmed.



120.

i Increase or decreased by touching the **+** or **-** symbols on either side of the value shown. Or touch on the value **0.0** itself, to touch type a new value.


Check the specifications for your fastener to determine the appropriate force to use



121.

i Another setup stroke is required to verify adjustments are acceptable.

122.



123.




Upper tool in motion

124.




Upper tool in motion

125.



Upper tool in motion

126.




COMPLETE INSERTIONS FOR STATION 1

i YES: If adjustments are acceptable.


i NO: If adjustments are NOT acceptable and more adjustments are needed.

127.




Upper tool in motion

128.




Upper tool in motion

129.



TIS is now UNLOCKED, allowing you to turn it to Station **2**. When in the correct position, the machine will automatically lock the TIS.


130.



Manually Place Fastener

Setup Stroke: Saves all the setup values such as Fastener pick up point, vacuum detection, length and tooling test.

131.




132.




Upper tool in motion

133.




Upper tool in motion

134.



Upper tool in motion

135.




YES: If adjustments are acceptable.



NO: If adjustments are NOT acceptable and more adjustments are needed.

136.




COMPLETE INSERTIONS FOR STATION 2




Upper tool in motion

137.




Upper tool in motion

138.



TIS is now UNLOCKED, allowing you to turn it to Station **3**. When in the correct position, the machine will automatically lock the TIS.






139.




Manually Place Fastener




Setup Stroke: Saves all the setup values such as Fastener pick up point, vacuum detection, length and tooling test.






Upper tool in motion




YES: If adjustments are acceptable.




NO: If adjustments are NOT acceptable and more adjustments are needed.




Upper tool in motion



Upper tool in motion




TIS is now UNLOCKED, allowing you to turn it to Station **4**. When in the correct position, the machine will automatically lock the TIS.




Manually Place Fastener




Setup Stroke: Saves all the setup values such as Fastener pick up point, vacuum detection, length and tooling test.



Upper tool in motion




Upper tool in motion




Upper tool in motion

152.




153.




i YES: If adjustments are acceptable.

i NO: If adjustments are NOT acceptable and more adjustments are needed.



154.



Upper tool in motion



SECTION 5 - OPTIONS

Component	Part #	Description	Picture
1. Work Light	15-01801	Perform safety system check procedures using "Testing the Safety System"	
2. Laser – Part Locating Light	H-1087	Provides a highly visible, easy to read, red beam of light over the lower tool to aid the operator in locating holes on larger parts. Increases productivity and decreases operator fatigue.	


SECTION 6 – MACHINE MAINTENANCE

This maintenance schedule is applicable for standard machine shop operating conditions. When operating under severe conditions such as heavy dust and dirt, increase the schedule to reflect such conditions.



DO NOT lubricate the Upper Tool Holder with any lubricant other than a small amount of lithium grease (white). ** Other products may interfere with the Safety System.

Maintenance Schedule

Component	Area	Maintenance	Schedule
Safety System	Upper Ram	Perform safety system check procedures using "Testing the Safety System"	Daily
Clean HMI Filter	Touch Screen Computer Back Cover	Blow out Filters with clean air.	Once a month (160 hrs)
Upper Tool Holder	Upper Ram	Inspect Continuity Springs and Pins	Once a month (160 hrs)
Upper Tool Holder (See warning above)	Upper Ram	Small amount of lithium grease (white)** between upper tool holder & cylinder rod Check this label	Once a month (160 hrs)
Upper Tool Holder	Upper Ram	 Replace Risk of Crushing label if peeling or damaged	Daily
Fan Filters	Electrical Cabinet	Remove filters and blow out filters with clean dry air.	Every 3 Months (480 hrs)
Shuttle Tooling	Shuttle Jaws	Inspect Springs and change out if they appear weak	Every 6 months (960 hrs)
Tooling Components	Flight Tubes	Inspect and change out if damaged	Every 6 months (960 hrs)
Hydraulic System Filter	Lower Hardware Insertion Machine Motor Compartment	Remove and replace cartridge Haeger Part No. 15-00888	Once a year (2000 hrs)
Hydraulic Fluid and Suction Filters	Lower Hardware Insertion Machine Motor Compartment	Drain fluid and change suction filters located inside the tank. Haeger part# 15-01131 Qty 2, refill fluid using AW Exxon Humble Hydraulic. H or equivalent.  Contact your local recycling center or governing agency for proper disposal of the old hydraulic fluid.	Once every 2 years (4000 hrs)

Maintenance Schedule (cont'd)

***Hydraulic Fluid**
Equivalent hydraulic oils may be used. It is the machine owner’s responsibility to determine which hydraulic oils in their area are equivalent to Exxon Humble Hydraulic H AW-32.

**** Lithium Grease**
Each Haeger machine is shipped with a tube of Lubriplate 630-AA, produced by Fiske Brothers Refining Company. In Europe, Fiske Brothers is represented by Total Deutschland GmbH.

Capacity Chart

<u>Machine</u>	<u>Gallons</u>	<u>Liters</u>
WT-4	22	83

Trouble Shooting

Problem	Source	Solution
Machine will not turn on	Stop button pushed	Rotate Red stop button clockwise. This will cause the stop button to unlatch and pop out for the start mode.
	Disconnect switch is in the off position on the electrical cabinet.	Turn disconnect to the on position on the electrical cabinet
		Open the cabinet and insure the disconnect switch attachment bar is still connected to the switch inside the cabinet.
		Inspect the condition of the disconnect switch handle for any damage and alignment to the attachment bar.
	No power to machine	Inspect to insure machine is plugged in to the correct power supply.
		Using a meter check the volts on the 3 phase disconnect switch inside the electrical cabinet to insure it matches the identification plate on the back of the machine.
	Circuit Breaker Tripped	Using a volt meter, insure the power coming into the machine is correct. You can look at the identification plate on the back of the machine for the correct volt requirements.
		There is a fault with either the motor or the safety board. To determine which is at fault, disconnect the three wires from the circuit breaker going to the motor and restore power. If circuit breaker still trips then go to next step. If circuit breaker does not trip, inspect motor wiring for damage and check electrical connections at motor including ground wire connection. If all wiring is ok and connections are tight change out motor.
		Check transformer for loose connections.
		Check volts on discharge side of transformer. If not correct change out transformer. If correct go to next step. Should be 19 VAC
		Check VDC between terminals T-14 (+) and T-74 (-) and they should read 24VDC. If not correct change out Dirty 24VDC power supply. If correct go to next step.

Trouble Shooting (continued)

Problem	Source	Solution
Machine will not turn on	Circuit Breaker Tripped	Check VDC between Terminals T-42 (+) and T-2 (-) and they should read 24VDC. If not correct change out Clean 24vdc power supply. Check to see if the green start push button lights up when depressed. If the push button lights up but motor will not start, manually depress the button on the Mag Starter. If the motor starts then go to next step. If the motor does not start replace Mag Starter.
Machine turns on but motor does not start.	Overload relay tripped	Reset overload relay. If Overload relay trips again check to insure the correct volts are being supplied to the machine.
		Check wires going to the motor for any signs of damage or loose connections.
		Inspect connections at motor for tightness and inspect ground terminal for tightness. If ok change out motor. If not ok fix problem and retest.
	No voltage going to motor.	Check for voltage at overload relay. If no voltage present on discharge side, change out overload relay. If voltage is present go to next step.
		Check connections at motor for tightness and check ground screw for tightness. If ok , check for voltage at motor. If ok, change out motor. If not ok inspect wiring for damage.
	Mag Starter shorted	Check to see if the green start push button lights up when depressed. If the push button lights up but motor will not start, manually depress the button on the Mag Starter. If the motor starts then go to next step. If the motor does not start replace Mag Starter.
		Check for 24vdc at terminal 14 on the Mag Starter. If there is no voltage, check F6 fuse for damage. If there is 24 vdc go to next step.
		Check for 24vdc at terminal 3 on the Green start push button. If there is no voltage check wire from terminal 14 on the Mag starter to terminal 3 on the green start push button for damage. If there is voltage go to next step.
		Check for 24vdc at terminal 4 on the green start push button when it is depressed. If there is no voltage, change out start push button. If there is voltage present then check the wire condition from terminal number 4 on the green push button to terminal 13 on the Mag starter for damage. Also check the P.C fan motor for continuity. The fan motor connects to the start push button on terminals X1 positive and X2 negative.

Trouble Shooting (continued)		
Problem	Source	Solution
	Safety relay board shorted	Remove wire T-61 from the safety relay board and ensure the wire is not touching anything. It will have 24vdc supplied to the wire. Try and start machine with T-61 disconnected. If machine starts up check all items on that circuit to find what is shorted; if the machine does not start up go to step 2.5 Power supply shorted. Reconnect wire T-61 and then remove the following wires one at a time and check if machine starts with each wire removed. If the machine starts with one of these wires disconnected, troubleshoot that circuit to find the short. T86, T85, T62, T63, T64, T65, T66, T67. Also pull relays R1, R2, R3, R6, K6 AND K9. If none of the wires or relays while disconnected allow the machine to start up, then change out the safety relay board.
	Power Supply Shorted	Check to ensure 24vdc is coming out of power supply. While the meter is still hooked up, depress the start button and if voltage drops low (1-7vdc) change out power supply.

Problem	Source	Solution
This next section deals with fuses blowing. Typically the problem is with a component shorted to ground. The trouble shooting method involves disconnecting wires to isolate components or electrical legs. Please follow the procedure outlines and do not skip steps. Caution needs to be taken because some wiring may be HOT. Ensure you have extra fuses and they are the correct AMP rating as the one currently in use		
F1 fuse blows	PLC Fault or faulty "Clean" transformer.	Remove wires T-4 and T-41 from the P.C board. Restore power and check if F1 fuse blows. If it does then change out the Clean 24vdc power supply unit. If it does not blow, go to next step.
		Reconnect wire T-4 and restore power. If F1 fuse blows, then turn off power and reconnect T-41 and go to 3.2.1. If F1 fuse does not blow then reconnect Wire T-4 and go to 3.3.1
	E-Stop shorted or P.C Board Shorted.	To isolate which leg on the E-Stop is shorted you will need to pull the following Fuses. F3, F2 and F6. Turn power back on to the machine and if F1 Fuse blows, Change out E-stop. If F1 does not blow, Replace Fuse F3. Turn power back on and if F1 Blows then follow the procedure for F3 fuse blowing. If F1 does not blow replace F2 Fuse. If F1 fuse blows then follow the procedure for F2 fuse blowing. If fuse does not blow then replace fuse F6. If F1 fuse blows then follow the procedure for F6 Fuse Blowing. If none of these solves the problem to a root cause, then change out P.C Board.

Trouble Shooting (continued)		
Problem	Source	Solution
	PLC or Expansion Module shorted.	3.3.1) Unplug both PLC and Expansion Module power plugs on the bottom of the units and turn on power. If Fuse F1 blows then check wiring to both units for shorts to ground. If fuse does not blow, then reconnect the PLC power plug and turn machine back on. If fuse F1 blows, change out the PLC. If the F1 fuse does not blow then reconnect the power plug for the Expansion Module. If the F1 Fuse Blows, change out the Expansion Module.
F2 fuse blows	Fan shorted	Check for a short from terminals T-33 and T-25. If no short found go to next step. If short is found, replace fan.
	Touch screen shorted	Unplug touch screen power cord and check for a short. If a short is found replace the touch screen. If no short is found go to next step
	Stop switch shorted	Check the stop switch for a short. If a short is found, replace the stop switch. If no short is found, contact Haeger Service Department
F3 fuse blows	Footswitch Shorted	Check wiring from the footswitch to the cabinet for damage. If wiring appears to be ok go to next step. If not ok, repair or replace wiring.
		Remove wire from terminal T-50 and replace fuse. Turn power back on and see if fuse blows. If fuse still blows go to 5.2. If fuse does not blow, change out the footswitch and reconnect wire to T-50
	Key Switch Shorted	Check wiring on the back of the key switch for tightness or damage. If wiring appears to be ok go to next step. If problem is found, repair as needed.
		Remove wires from terminals T-49 and T-67 and replace fuse. Turn power back on and if the fuse blows then go to 5.3. If fuse does not blow then replace key switch and reconnect T-49 and T-67 wires.
	Relays Shorted	Pull relays R1 and R2 and inspect the pins on the back for damage. If damage to the pins are found replace the relays. If no damage is found go to 5.4.
	E-stop, Analog Module, CET or Pressure transducer shorted.	To determine which component is shorted remove the wire terminals T-48 (analog module), T-45 (CET), and T-46 (pressure transducer). Restore power and if F1 fuse blows replace or inspect E-stop wiring for shorted to frame. If fuse does not blow, reconnect Wire T-46 and Turn on power. If F1 fuse blows change out the pressure transducer. If Fuse F1 does not blow reconnect wire T-45. If F1 fuse blows then change out the CET module. If Fuse F1 does not blow then reconnect wire T-48. If F1 fuse blows, unplug the main connector on the front of the analog module and turn

		power back on. If Fuse F1 still blows then change out the analog module. If F1 fuse does not blow, turn off power and check wiring on connector for any shorts to ground.
F4 Fuse blows	Short in MAS	Unplug all MAS connectors from the back of the machine at the quick disconnects. Insure you reconnect them to the proper location to avoid start up problems. Replace fuse and turn power on. If fuse still blows go to 5.2. If fuse does not blow then check for a short in one of the MAS and repair as needed.
	Line Filter Shorted	Replace Line Filter.
F5 or F21 fuse blows	Failed 4.8A power supply	Change out power supply.
F6 Fuse Blows	F6 ties into a lot of components and is the most difficult to troubleshoot. The process of elimination will be used so please follow each step before moving on.	To isolate which leg is causing the problem pull the following relays from the board. R1, R2, R3, R6, K6, K9 AND K5. Turn on power and see if F6 fuse blows. If F6 fuse blows then go to 8.2 If F6 fuse does not blow then go to 8.3
	Mag Starter, Green Start Push Button, Buzzer in the P.C control Cabinet, Non conductive Key Switch, Safety Switch, or the stepper motor for the upper tooling is shorted.	To isolate the components to find the cause of the short please follow closely. Replace all relays from step 8.1.1 Next remove wires T-63, T-60, T-86, T-62, T-67& T-61 Turn on power and if F6 fuse blows then reconnect all the wires back and Change out mag starter. If fuse does not blow then reconnect T-15 and turn power back on. If fuse F6 blows, change out green start push button. If the fuse does not blow, reconnect wire T-62. If F6 Fuse blows, disconnect all MAS plugs at back of machine and reconnect them one at a time with turning the power on and off after each one is connected to find the one causing the outage. If the F6 does not blow after wire T-62 is connected, reconnect wire T-67. If fuse F6 blows, change out the conductive key switch. If F6 Fuse does not blow, reconnect wire T-86. If F6 fuse blows, change out the buzzer inside the P.C console. If F6 fuse does not blow, Reconnect wires T-60 and T-63. If F6 Fuse blows, change out the stepper Driver Board.
	Relays shorted	Pull Relays R1, R2, R3, K5, K6, K9. Insert one really at a time and turn on power to see if the fuse F6 blows. Until you find the relay or path causing the short. Then Change out they relay.
Fuse F8 blows	Safety Switch	Check to ensure that wire T-3 is connected to the grounding strap on the safety switch.
Fuse F9 blows	6 vdc rectifier shorted.	Pull fuse F-10 and turn on power. If F9 fuse blows, change out P.C Board or replace the 6 volt rectifier on the board.

Trouble shooting (continued)		
Problem	Source	Solution
Fuse F10 blows	6 Vdc rectifier power out being shorted.	Change out P.C Board.
Fuse F20 blows	24 vdc clean power supply shorted	Change out 24vdc clean power supply.
Fuse F22 Blows	Fan Shorted	With Power off Disconnect Wires T-34 and T-33. Turn on power and If F22 Fuse Still Blows Contact Haeger Service. If fuse does not blow, turn off power and reconnect T-33. Repeat process and turn on power. If Fuse F22 Blows, change out the fan in the electrical cabinet. If fuse F22 does not blow, turn off power and reconnect T-34. Turn on power and if fuse blows check e-stop for wiring damage or shorts to ground.
Fuse F23 Blows	Proportional Amplifier shorted.	Change out Proportional Amplifier.
Filter leaking at seal.	Filter is dirty	Change out filter
	Check valve in filter has came apart	Remove filter housing, inspect condition of check valve. If damaged replace housing.
Ram will not come down	Machine not turned on.	Ensure machine is and motor is turning.
	Top of stroke limit not met.	Ensure ram is at full top of stroke.
		Check top of stroke setting under the administration screen for proper set up
	CET not working.	Check to ensure yellow string is connected to top of ram and that there is no slack. If slack is present check alignment of CET to top of ram or change out CET unit.
	Top of Stroke set point incorrect.	Check the Top Of Stroke set point on the Change PLC Values screen. Should be at least 10 numbers below the current value reading with the ram at full up position.
	Foot switch Shorted.	Check the diagnostic screen under inputs or look at PLC lights inside cabinet, and check for X4 to be checked or lighted when the down foot pedal is pressed. If the light does not come on then check for 24vdc at terminal T-50 to ground. If power is present then change out foot switch. If power is not present then check Fuse F3 for damage.
	Relays not working.	Check relays K6 and K9 for proper operation.

Trouble shooting (continued)		
Problem	Source	Solution
	16.7) Ram is shorted to frame	16.7) Check to see if R3 or R6 are activated. If these are activated and the upper tool is not touching lower tool, then you must look for a short from the Ram To Frame. Typically this will happen because of a loose guard or one that has some metal showing at or near the top portion of the ram. Note The ram must be completely isolated form the frame except for tooling contact.
	Hydraulic leak or broken hose.	Ensure there are no hydraulic leaks at hose connections and fittings. Also check to ensure there is enough hydraulic fluid in the tank.
	4 way valve sticking	Check to see if the light on the down solenoid is coming on when the down footswitch is depressed. If the light is coming on, manually activate the down solenoid and see if the ram comes down. If the ram comes down then change out the 4way valve. If the ram does not come down check for other hydraulic problems.
Ram will not go up	Top Of Stroke Setpoint incorrect.	Check the Top Of Stroke set point on the Change PLC Values screen. Should be at least 10 numbers below the current value reading with the ram at full up position.
	17.2) PLC not working	17.2.1) Check for output Y9 on the PLC to see if it is on. If not check to see if X4 on the PLC is on when stepping on the up pedal at the foot switch. If X4 does not come on check for a shorted foot switch. If Y9 on the PLC does come on then go to 17.2
	K5 Relay burnt	Inspect Relay K5
	Foot Switch shorted	Check the PLC input X5 is coming on when the up pedal is depressed.
	4 way up solenoid valve not working.	Visually check the up solenoid valve on the 4way to see if it lights up when the up pedal is pressed. If it does light up the manually depress the 4way valve. If the ram goes up, change out the 4 way valve. If there is no light on the up solenoid, verify wiring and power going to up solenoid.
	loose wire	Verify there is power at T-20 (24vdc) and then check for power at Solenoid valve. If no power at valve but there is power at T-20, check for a broken or loose wire.
Fastener will not feed	MAS is empty.	Check to ensure there is enough fasteners in the MAS.
	Fasteners are jammed in orientation or singulation modules.	Check the orientation module and the singulation module to ensure that there are no fasteners jammed in either.

Trouble shooting (continued)		
Problem	Source	Solution
	Air is not set to 90psi	Check the air supply.
	Air blast is wide open not allowing enough air to feed fastener.	Check to ensure the air blast is not full open not allowing enough air to actuate the air cylinder on the singulation module.
	Singulation module air cylinder is jammed or not working.	Check the operation of the air cylinder to ensure there is no binding.
	Fastener is jammed in feed hose.	Check to ensure the feed hose is not kinked and there are no fasteners jammed in hose.
	Air Timer Is turned down to zero.	Check the Air timer and the air blast settings to ensure they are properly set to allow enough time to get fastener down to upper tool.
Nut is feeding upside down.	Feed Hose is not turned 180deg.	Check to ensure the feed hose is turned 180deg from the singulation module to the upper tool holder.
	Incorrect orientation module or singulation module.	Check to ensure the correct modules are installed for the fastener you are running.
Ram comes down and taps and then returns up. No pressure is built.	Running non-conductive material while in the conductive mode.	Ensure that you are in the right mode for the material you are running.
	Lower tooling or material is dirty.	Check the condition of the lower tooling and the material. If the material is dirty this will not allow tooling contact to take place.
	continuity Spring and pins worn.	Check the condition of the continuity springs and pins. Also check to ensure the upper tooling is not binding on the shaft.
	Safety switch not working	Check the condition of the safety switch. Bring the ram down to mid stroke and lift up on the upper tool. If the ram does not return up then inspect the safety switch system for damage.
	Machine is sensing pressure being built.	Check the pressure transducer for proper operation by turning off the machine and checking the pressure reading on the administration screen. If pressure shows zero start machine and take reading. If pressure rises above 30psi turn off machine and inspect the hydraulic system.

Trouble shooting (continued)		
Problem	Source	Solution
		Check the condition of the proportional amplifier.
	F3, F6, F10 or F9 Fuses are burnt.	Check condition of fuse
	Relays R3 or R 6 burnt or not working.	Check to see if relays are cycling. Check contacts for burnt conditions. If the contacts appear burnt, change out relay.
Ram Comes Down, builds pressure, but will not return up	Machine in set up mode.	Check run screen to ensure it is not in set up mode. This can also be determined by a yellow run screen.
	Pressure is not being sensed.	Check the pressure reading under the administration/ change plc values. The reading should be no more than 30 at idle. Also check the set point to ensure it is at 60 to 90. If the set point is not correct, adjust to 90. If there is no pressure being shown at idle, Check the wiring and plug going to the pressure transducer for damage or loose connections.
		While watching the pressure screen, operate machine and verify the pressure goes above the set point. Example: If pressure only reaches 60 and set point is at 90, adjust set point to 55.
Continuously getting TPS errors.	TPS sensitivity set to low.	Reset TPS using the part and fastener for the job.
	TPS set at high pressure.	On older machines - set the TPS using min pressure. On high speed machines it does not matter what force is selected.
	Continuity pins and spring worn causing incorrect set point.	Check the springs and pins in the upper tool holder for damage or collapsed springs.
P.C Error codes	Numerical overflow error	This error will come up when too much information had been entered on any given line or too many characters. Example would be TPS setting containing astrics. Look for this occurrence on all information windows in the run screen, admin screen, password screen, program screens.
		If you cannot find the problem, reload the software and this will reset default values.

Weekly Care & Maintenance

This maintenance schedule is applicable for standard machine shop operating conditions. When operating in severe conditions such as heavy dust or dirt or 24 hour running. Increase the schedule to reflect such conditions.

(MAS 350): Care & Maintenance



- Dirt, grease, debris builds up over time in the bowl.
- To avoid getting debris in the bowl, lift, rather than pour, the hardware into the bowl
- 1st: Remove all fasteners from bowl.




- 2nd: Use dry compressed air to blow out debris.




- **Eye protection** must be worn.



- 3rd: Wipe bowl clean with dry cloth.

-  If dirt, grease is present, use **Acetone** with gloves and a clean cloth to wipe off build up.

-  Read all warnings on cleaning solution container & follow recommendations for safe handling and storage.



DO NOT use rubbing alcohol, WD-40, diesel, gas, etc., to clean MAS 350 composite bowls!

Flight Tube: Care & Maintenance



- Dirt, grease, debris builds up over time in the tubes.
- It is recommended to blow out flight tube after each tool change.
- 1st: Detach tube(s) from MAS 350 Module and upper tool changer.



- 2nd: Use dry compressed air to blow out debris.



- **Eye protection** must be worn.

Denatured Alcohol

- 3rd: Rinse inside of tube with Denatured Alcohol and air dry.



- Read all warnings on cleaning solution container & follow recommendations for safe handling and storage.




- **DO NOT use** rubbing alcohol, WD-40, diesel, gas, etc., to rinse out inside of flight tubes!
- **DO NOT use** Silicone Spray as a lubricant on this machine.

Upper Tool Changer: Care & Maintenance



- It is recommended to blow out the upper tool changer weekly or more frequently based on usage.



- 2nd: Use dry compressed air to blow out debris.



- **Eye protection** must be worn.



- **DO NOT use** rubbing alcohol, WD-40, diesel, gas, etc., to clean tool changer slides!
- **DO NOT use** Silicone Spray as a lubricant on this machine.

Upper Tool Holder: Care & Maintenance



- It is recommended to inspect the upper tool holder and its contacts weekly or more frequently based on usage.



- **DO NOT** use Silicone Spray to lube inside of holder.
- **If necessary, Denatured Alcohol** can be applied to a clean cloth to remove dirt and grease.



DO NOT use rubbing alcohol, WD-40, diesel, gas, etc., to clean contacts or any part of the holder!



- 1st: Turn round thumb screw counter clockwise to allow tool holder to slide off.



- 2nd: Inspect springs and contacts and wipe off with clean dry cloth.



- 3rd: Wipe off **all** metallic areas with clean dry cloth.




- 4th: Wipe inside of tool holder with clean dry cloth.




- 5th: Apply a **THIN FILM** of **WHITE LITHIUM GREASE** on metallic areas only.
- 6th: Re-install springs with metal contactors in body of tool holder, slide body over sensor and tighten thumb screw.



Diagnostics: From Main Screen






Digital Inputs (DIxx): These are inputs for the PLC from various points on the electrical board. These Inputs determine what Outputs will be turned on at certain times.

Digital Outputs (DOxx): These are Outputs from the PLC to various points on the board to control Relays, Air Cylinders, Modular Auto Feed (MAS), and other functions.

Analog Inputs (AIxx): These are inputs for the PLC from various sensors in the electrical board, such as the Ram Pressure, Ram Position and Vacuum Sensor.


Analog Outputs (AOxx): These are Outputs from the PLC to various points on the board to control the Ram Force and the MAS Vibration

Note: Your Machines PLC Version number will be requested by customer service to trouble shoot any field issues.



PLC1 I/O Screen

PLC, I/O List



PLC I/O

DIGITAL INPUTS

- DI0 Power On
- DI1 Safety Switch 1
- DI2 Safety Switch 2
- DI3 Non-Conductive Key
- DI4 Tool Contact 1
- DI5 Tool Contact 2
- DI6 Spare
- DI7 Auto Cycle
- DI8 Footswitch UP
- DI9 Footswitch DOWN
- DI10 Spare
- DI11 TIS Sensor 1
- DI12 TIS Sensor 2
- DI13 TIS Sensor 3
- DI14 Shuttle Retract
- DI15 Shuttle Extend

DIGITAL OUTPUTS

- DO0 Start Light
- DO1 Stop Light
- DO2 Buzzer
- DO3 Non-Conductive Mode
- DO4 Vacuum
- DO5 Blow off
- DO6 MAS Bowl Value
- DO7 Spare
- DO8 Ram UP
- DO9 Ram DOWN
- DO10 Bypass Valve
- DO11 MAS Eject
- DO12 MAS Blow off
- DO13 TIS Lock
- DO14 Spare
- DO15 Shuttle Extend

Analog INPUTS

- AI0 Ram Pressure
- AI2 Vacuum Sensor
- AI4 Ram Position

Analog OUTPUTS

- AO0 Ram Force
- AO6 MAS Vibration


Schematics & Diagrams

Schematics and Diagrams are customized to accurately depict your machine and will not be bound in this operations manual. They will be delivered separately on large format paper in an effort make them legible and easy to read.

Typical Drawing List:

- PLC Schematic
- Safety Relay Board - Internal Schematic
- Safety Relay Board - External Schematic
- Wiring Schematic
- Hydraulics Schematic
- Pnuematic Schematic
- Electrical Ladder Diagram

Customer Service



Haeger is proud of its reputation for providing you with first-class support. Our mission is to offer you cutting edge technology machines that will provide your organization with world-class performance and value. Contact us today.

NEED SERVICE? *A service tech will contact you within 24 hours*

Call your Haeger Representative our contact information is the front of this manual.

To save time, please be prepared to give your area Haeger Representative the following information:

1. Your name.
2. Your company's name, location and telephone number.
3. The Model Number of your Haeger machine.
4. The Serial Number of your Haeger machine.
5. A very detailed description of the problem.
6. What steps you have already taken to resolve your problem.
7. How the machine responded to each of the steps.
8. Visit our web site at www.haeger.com and check out our service web page Custom Support/service.

SERVICE TEAM

Headquarters

811 Wakefield Dr.
Oakdale, CA. 95361
Toll Free: (800) 878-4343
Phone: +1 (209) 848-4000
Fax: +1 (209) 847-6553
Email: info@haeger.com
Website: www.haeger.com

Haeger Europe

Textielstraat 18
7575 CA Oldenzaal
The Netherlands
Phone: (+31)6 295 549 27
Fax: +31 541 532 400

CHAT LIVE

9AM-3PM

[Click Here To Chat](#)

Live Chat by **Live Person**

Warranty

Limited Warranty

1. **EXCLUSIVE WARRANTY:** This warranty is exclusive and in lieu of all other express or implied warranties including, without limitation, the implied warranties or merchantability and fitness for a particular purpose.
2. **EFFECTIVE DATE:** The warranty period starts from the date of installation by Distributor or Haeger Factory Technician, or from date of receipt if self-installed by the customer.
3. **PRODUCTS:** As to products, any defects in materials will be corrected without charge for parts or labor for a period of one year from warranty effective date. Products include the Haeger Insertion Machine, Modular Autofeed System (MAS), and Factory Installed Accessories.
4. **TOOLING:** As to tooling, any defects in materials or workmanship will be corrected without charge for labor or parts for a period of one year from the date of receipt. Tooling includes all Automatic Tooling, all Standard Manual Tooling, and all Special Manufactured Tooling.
5. **PROCEDURE:** You, the customer must notify Haeger, Incorporated promptly of any breach of this Limited Warranty by calling or writing to:

<u>Haeger, Inc. Headquarters</u>	<u>Haeger Europe</u>
811 Wakefield Drive Oakdale, CA 95361 Phone: +1 (209) 848-4000 Fax: +1 (209) 847-6553	Textielstraat 18 7575 CA Oldenzaal The Netherlands Phone: +31 541 530 230 Fax: +31 541 532 400

Haeger, Incorporated, at its option, may elect to replace or repair the machine or part of the machine either in the field or may direct you to ship it to back, freight prepaid.


6. **LIMITATIONS:** Haeger, Incorporated, will not be liable in any event for incidental or consequential damages or for failure due to wear and tear, abuse, improper operation or maintenance, repair or modification by personnel not authorized by Haeger, Incorporated or other circumstances beyond the control of Haeger, Incorporated.

SECTION 7 – PARTS LIST

Description

The **Parts** in this section of the manual are listed by **Item Number**, **Part Number**, **Description** and **Quantity**.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	XX-XXXXX	XXXXXXXXXX	X


Item Numbers  : Are depicted with in a circle with an arrow pointing to the specific **part** or **assembly**.

Part Number: This is the most important number on the page. It identifies a specific item in Haeger's inventory. To avoid delays when ordering parts, be very sure the **Part Number** and **Quantity** are stated correctly!

Description: This is Haeger's brief description of the part. For purchased parts, it may also include the manufacturer and their part number.

Quantity: This represents the total quantity of the particular **Part** which is used in the complete assembly. When ordering **Parts**, it may not always be necessary to order the number of parts listed. Order only the quantity that is required to make the repairs.


Parts List - Main Assembly



Parts List - Main Assembly (cont'd)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-02721	WELDMENT, FRAME, WT (-4)	1
2	15-02738	TOP COVER, SHEET METAL, WT (-4)	1
3	15-02734	CABINET, ELECTRICAL, WT (-4)	1
4	15-02725	BASE FRAME, WT/OT (-4)	1
5	15-02726	MANIFOLD TABLE, BASE, WT (-4)	1
6	15-02736	HYDR. LINES COVER, SHEET METAL, WT / OT (-4)	1
7	15-02727	MOTOR & PUMP TABLE, BASE, WT (-4)	1
8	15-02729	MOTOR & PUMP PANEL, BASE, WT (-4)	1
9	15-02728	MANIFOLD PANEL, BASE, WT (-4)	1
10	15-02730	BACK HYDRAULICS PANEL, BASE, WT(-4)	1
11	15-02731	FRONT HYDRAULICS PANEL, BASE,WT (-4)	1
12	15-01160	LEVELING FOOT M16X2	4
13	15-00030	LIFTING STRAP	1
14	15-03038	MAINTENANCE COVER, CYLINDER PANEL, 824 (-4) OT/WT	1
15	15-41593	ASSY, TIS-3 QUICK DISCONNECT, WT4e	1
16	15-00291	824 WT & 824+ UPPER TOOL HOLDER ASSY.	1
17	15-03078	COMPUTER, TOUCH SCREEN	1
18	15-40017	ASSY, QUICK MOUNT UPPER TOOL, WT (-4)	1
19	15-02740	FRONT COVER, CYLINDER, WT (-4)	1
20	15-03148	CYLINDER TOP COVER, (-4e) WT/OT	1
21	824 P-STOP		1


Parts List - MAS 350 Bowl Assembly



Parts List – MAS 350 Bowl Assembly (cont'd)


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	SEE TABLE	BOWL, MAS 350	1
2	15-01702	DOWEL PIN, 4 x 10mm, HARDENED STEEL	2
3	15-02923	BLOCK, MOUNTING, MAS350	1
4	15-02924	LEVER, LOCKING, MAS 350	1
5	15-00273	1/4" TUBE STRAIGHT FITTING	2
6	15-02920	DOWEL, BUSHING #10, MAS 350	2
7	15-02921	WEIGHT, COUNTER, MAS 350	1
8	15-02922	WIPER, M8, M10 NUT, MAS 350	1
9	15-01961	DOWEL PIN, 3MM x 6MM	1
10	15-02914	DOOR, GATE, MAS 350	1
11	H-3711	O-RING, 1/2 X 3/8 X 1/16	2
12	15-03039	SCREW, M5X0.8 X 10MM, THUMB WITH SHOULDER, STAINLESS	2
13	H-3738	SHCS, M5 x 0.8 x 12mm, BLACK OXIDE	2
14	11-00495	FLAT WASHER, M5, STEEL	3
15	15-01392	LOCK WASHER, M5, STEEL, ZINC PLATED	1
16	15-00484	SHCS, M5 x 0.8 x 20mm, STAINLESS STEEL	1
17	H-3899	FLAT WASHER, M4, STEEL	2
18	H-3745	BHCS, M4 x 0.7 x 8mm, STAINLESS STEEL	2

Parts List – Upper Tool Holder Assembly



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-00095	BODY, 824 WT & 824+ UPPER TOOL HOLDER	1
2	11-00016	CONTINUITY GUIDE PIN	3
3	11-00114	CONTINUITY SPRING	3
4	11-00239	M5 THUMBSCREW ASSEMBLY	1
5	11-00236	STANDARD TOOL ADAPTER	1
6	11-00238	SHSS, M5 X 6, BLACK OXIDE	2
7	11-00242	SHSS, M6X1.0 X 6, BLACK OXIDE	5


Parts List - Quick Mount Assembly



Parts List – Quick Mount Upper Tool Assembly (cont'd)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-02782	LOCKING AXLE, QUICK M., MULTI-SHUTTLE, WT (-4)	1
2	15-01674	SHCS, M3 x 0.5 x 25, STEEL, BLACK OXIDE	8
3	15-02790	CONNECTOR MALE, 1X AIR & 3X 24V, WT (-4)	2
4	15-02784	LEG LOCKING SIDE, QUICK MOUNT UPPER, WT (-4)	1
5	15-02785	LEG POSITION SIDE, QUICK MOUNT UPPER, WT (-4)	1
6	H-3738	SHCS, M5 x 0.8 x 12mm, BLACK OXIDE	2
7	15-01601	M6, WASHER, ZINC PLATED	1
8	11-00042	LEVER, LOCKING	1
9	11-00319	SHCS, M6 x 1.0 x 20MM, STAINLESS	2
10	H-3681	SPRING PLUNGER, M5, STEEL	1
11	15-41871	ASSY, MULTI-SHUTTLE 2, WT (-4)	1
12	15-02786	BODY, QUICK MOUNT UPPER TOOL, WT (-4)	1
13	11-00238	SHSS, M5 X 6, BLACK OXIDE	1
14	15-03079	NUT, HEX, M12 X 1.75, THIN, STAINLESS	1


Parts List - Muti-Shuttle 2 Assembly



Parts List - Muti-Shuttle 2 Assembly (cont'd)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-01870	SLIDE TABLE, MXS6 MULTISHUTTLE	1
2	15-02883	INSULATOR PLATE, MULTI-SHUTTLE 2	1
3	15-02881	ALIGNMENT PLATE, MULTI-SHUTTLE 2	1
4	15-02882	MOUNTING PLATE, MULTI-SHUTTLE 2	1
5	H-3935	FHCS, M4 x 0.7 x 12MM, BLACK OXIDE	7
6	15-01754	DOWEL PIN, 1/4" X 1/2", HARDENED STEEL	4
7	H-3871	SHSS, M5 x 0.7 x 12MM, BLACK OXIDE ALLOY STEEL	2
8	H-3815	SHCS, M6 x 1.0 x 12mm	3
9	15-02884	ALIGNMENT TRACK, MULTI-SHUTTLE 2	1
10	H-3738	SHCS, M5 x 0.8 x 12mm, BLACK OXIDE	2
11	15-01546	TUBE CONN MOUNT, MULTISHUTTLE	1
12	15-01974	M2.5-.45 X 10MM STEEL SHFS	4
13	15-01557	MOUNT, TUBE CONNECTOR, WT & OT (-3)	1
14	15-01852	MODULE PLATE, MULTISHUTTLE	1
15	H-3548	10-32X1/4 SET SCREW	1
16	H-3681	SPRING PLUNGER, M5, STEEL	1
17	15-02057	FHCS, M3 x 0.5 x 10mm	6
18	15-01558	LID, TUBE CONNECTOR, WT & OT (-3)	1
19	15-01709	FHCS, M2 x 0.4 x 4, BLACK OXIDE	1
20	15-02513	SPRING BLOCK, MULTISHUTTLE	1
21	15-01867	SHOCK ABSORBER, MULTISHUTTLE	1
22	H-3872	SHCS, M3 x 0.5 x 8MM, BLACK OXIDE	2
23	15-02885	T-BRACKET, MULTI-SHUTTLE 2	1
24	15-02789-1	END CAP, CONNECTOR, MULTI-SHUTTLE 2	2
25	15-02789	FEMALE, CONNECTOR, MULTI-SHUTTLE 2	2
26	15-01804	M4 X 18 SHCS	8


Parts List - HMI Arm Assembly



Parts List – HMI Arm Assembly (cont'd)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-02769	SUB-ASSY, HMI ARM	1
2	15-02827	USB CONNECTOR W/ CAP, WT & OT	1
3	H-1071	ELECTRICAL BUZZER	1
4	10-01327	FLAT WASHER, M12, ZINC PLATED	4
5	H-3785	LOCKWASHER, M12, STEEL, ZINC PLATED	4
6	H-3741	SHCS, M12 x 1.75 x 50MM, STEEL, BLACK OXIDE	4
7	15-03065	BUTTON, E-STOP, PUSH	1
8	15-03068	BUTTON, RED LED, PUSH	1
9	15-03067	BUTTON, GREEN LED, PUSH	1
10	15-02459	INTERFACE LABEL, WT & OT 4E	1
11	15-03066	SWITCH, KEY	1

Parts List - TIS Assembly



Parts List - TIS Assembly (cont'd)


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-00449	SHCS, M3 x 0.5 x 14MM, STAINLESS	2
2	15-01295	VINYL CAP BLUE	1
3	15-01296	VINYL CAP GREEN	1
4	15-01297	VINYL CAP RED	1
5	15-01298	VINYL CAP YELLOW	1
6	15-01585	COVER, BASE, TIS-2	1
7	15-01586	HUB, TIS-2 ROTATION	1
8	15-01587	LOWER TOOL ARM, TIS-2	3
9	15-01588	BASE COVER, ELECTRICAL, TIS-2	2
10	15-01589	COVER, LOWER TOOL ARM, TIS-2	1
11	15-01591	LOCKING PIN, ROTATION, TIS-2	1
12	15-01592	AXLE, TIS-2 ROTATION	1
13	15-01596	AUTOMATIC ARM, LOWER TOOL, TIS-2	1
14	15-01667	SHCS, M4 x 0.7 x 8mm, BLACK OXIDE STEEL	1
15	15-01668	DOWEL PIN, 3/16" x 1/2", HARDENED STEEL	8
16	15-01669	NEEDLE BEARING, 1"	1
17	15-01674	SHCS, M3 x 0.5 x 25, STEEL, BLACK OXIDE	4
18	15-01675	HCS, M10X1.5X25MM, STEEL, ZINC PLTD, 8.8	1
19	15-01677	BEARING WASHER, M10	2
20	15-01678	NEEDLE BEARING, M10	1
21	15-01681	SLEEVEING, 3/8" ID X 3', BRAIDED POLYWSTER	1
22	15-01705	FHCS, M5 x 0.8 x 16mm, BLACK OXIDE, CLASS 10.9	4
23	15-02063	DOWEL PIN, 3/16" ID x 1/2" LG, ACETAL	1
24	15-02262	M2.5-.45 X 10MM STEEL SHFS	21
25	15-02493	WASHER, SERRATED, M10	1
26	15-02562	DOWEL PIN, 3/16" x 1/4"	1

Parts List - TIS Assembly (cont'd)

Create Better Ideas


27	15-02681	CABLE STRAIN RELIEF INSERT, MODULAR 2X6MM	1
28	15-02995	SENSOR UNIT, TIS-2, QUICK DISCONNECT, WT(-4)	1
29	H-169-6	WASHER, LOWER TOOL HOLDER	1
30	H-2535	QUICK DISCONNECT, 1/4"	1
31	H-2545	BULKHEAD, FEMALE QUICK DISCONNECT, 1/4"	1
32	H-2610	FITTING, TUBE REDUCER, 1/4" to 5/32"	1
33	H-3738	SHCS, M5 x 0.8 x 12mm, BLACK OXIDE	4
34	H-3866	ELBOW, 10-32 x 5/32, PLASTIC	1
35	15-02997	BASE TOOL HOLDER, TIS-2 QUICK DISCONNECT, WT(-4)	1
36	15-03031	AIR CYLINDER, SPRING RETURN, 12MM BORE	1
37	15-00286	5/32" TUBE, POLYURETHANE	0.83
38	15-00285	TUBING, 1/4", POLYURETHANE	1.33
39	15-01754	DOWEL PIN, 1/4" X 1/2", HARDENED STEEL	2

Parts List - Vacuum Generator Assembly




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-02241	VACUUM GENERATOR BRACKET, WT-3 & OT-3	1
2	10-00209	1/8" BRAS CL. NIPPLE	2
3	10-00210	BRASS BREATHER, 1/8"	1
4	10-00211	1/8" BRASS TEE	1
5	11-00587	24V SOLENOID VALVE	1
6	11-00589	VACUUM GENERATOR W/	1
7	14-00638	AIR FITTINGS	1
8	15-00890	BHCS, M4 x 0.7 x 25mm, ZINC PLATED	2
9	15-01325	FITTING: BUSHING BRASS 1/4 MALE NPT X 18 FEMALE NPT	1
10	H-5020	SWIVEL ELBOW, 90 DEG, 1/8 NPT X 1/4 TUBE	1
11	15-02158	Vac Switch ANALOG VDC	1

Parts List – Service Tray Assembly




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-01294	Part Bin 7 x 4 Yellow	1
2	15-01291	Part Bin 7 x 4 Dark Blue	2
3	15-01299	Parts Tray Holder	1
4	15-01292	Part Bin 7 x 4 Medium Green	1
5	15-01293	Part Bin 7 x 4 Red	1
6	11-00179	Service Tray Arm	1
7	11-00184	Service Tray Post	1

Parts List – Positive Stop System Assembly



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-00116	POSITIVE STOP BASE PLATE	1
2	15-00115	POSITIVE STOP CLAMP PLATE	1
3	15-00117	POSITIVE STOP INNER TUBE	1
4	15-00683	ASSY, POSTIVE STOP SLOTTED TUBE	1
5	15-00119	POSITIVE STOP OUTER TUBE	1
6	15-00120	NUT, POSITVE STOP, 824+, WT & OT (-3)	1
7	15-00046	CET CONNECTING BAR	1


Parts List – Hydraulic Cylinder Main Assembly



Parts List – Hydraulic Cylinder Main Assembly (cont'd)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-02889	HYDRAULIC CYLINDER, 8 TON, WT & OT (-4)	1
2	N/A	POSITIVE STOP SYSTEM ASSEMBLY	1
3	11-00271	824 CYL. INSULATION SHOE	1
4	h-3804A	5/8 BOLT INSULATION	2
5	h-3804B	5/8 BOLT INSULATION	2
6	15-00045	824 FRONT J- FRAME MOUNT BLOCK	1
7	H-3801	5/8-18 FLANGE NUT	4
8	H-3802	5/8 HARDENED FLATWAHSER	4
9	H-3803	WASHER, INSULATOR, 5/8"	4
10	15-00295	CET *4 SERV <VS9 15-01957 632699	1
11	15-02891	ASSY, HYDRAULIC TUBE, EXTEND	1
12	15-02892	ASSY, HYDRAULIC TUBE, RETRACT	1
13	15-00040	CET MOUNTING BRACKET	1
14	15-03072	7/16-20 x 1/4-18, 90 DEG ELBOW	2
15	15-00291	UPPER TOOL HOLDER ASSEMBLY	1

Parts List – Electrical Cabinet High/Low Voltage Assembly



Parts List – Electric High/Low Voltage Cabinet Assembly (cont'd)


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-02734	CABINET, ELECTRICAL, WT (-4)	1
2	15-02744	LOW VOLTAGE PANEL, ELECTRICAL, WT (-4)	1
3	15-02745	HIGH VOLTAGE PANEL, ELECTRICAL, WT (-4)	1
4	15-01719	POWER SUPPLY 120W 5A 24VDC (CLEAN)	2
5	15-00715	SAFETY RELAY BOARD	1
6	15-02907	PLC RIO GALIL 47202	1
7	15-02773	CONTROLLER CARD, MAS 350,115V., 50-60 Hz. (optional)	1
8	15-00178	TRANSFORMER, 750 VA	1
9H	15-03084	High Voltage: Lenze VFD/ABB, 5HP 380- 480VAC	1
9L	15-03083	Low Voltage: Lenze VFD/ABB, 5HP 200-240VAC	
10	15-01128	AMPLIFIER	1
11	10-01145	FUSE HOLDER 600V 30A DIN MOUNT	2
12	15-00137	CONTACTOR 24 VDC	1
13H	10-00670	High voltage: OVERLOAD RELAY	1
13L	15-00139	Low voltage: OVERLOAD RELAY	
14	15-03064	EATON, AUXILLARY CONTACT 1NO-1NC	1
15H	10-01154	High Voltage: CIRCUIT BREAKER	1
15L	15-00414	Low Voltage: CIRCUIT BREAKER	
16	15-00219	DISCONNECT SWITCH	1
17	15-02492	FAN GUARD 120 MM FAN	1
18	15-01752	GROUND STRIP, 21 PIN	1
19	15-03092	DISCONNECT GUARD	1
20	15-03210	INTAKE FILTER	1
21	15-03086	EMC Filter, 480VAC, 16A	1

Chose High **OR** Low Voltage
part # for your machine

Chose High **OR** Low Voltage
part # for your machine


Chose High **OR** Low Voltage
part # for your machine

Parts List – Printed Circuit Board Assembly



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-00715	SAFETY RELAY BOARD	1
2	15-00135	RELAY, SPDT	5
3	11-00376	FUSE 2 AMP	5
4	15-00152	FUSE 5 AMP	1
5	15-00451	FUSE 0.5 AMP	2
6	15-00129	FUSE 1 AMP	1
7	11-00375	FUSE 4 AMP	1
8	15-00130	FUSE 1.6 AMP	3
9	15-00133	FORCE GUIDED RELAY 24VDC 3N.O 1 N.C. (462-1027)(3MOPO)	2
10	15-00134	FORCE GUIDED RELAY, 6VDC 3.N.O. 3 N.C.(462-1026)	2

Parts List – Hydraulic Reservoir Assembly




Parts List – Hydraulic Reservoir Assembly (cont'd)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	10-00087	BLACK RUBBER SEAL, 3/16 X 1	1
2	11-00319	SHCS, M6 x 1.0 x 20MM, STAINLESS	20
3	15-00226	LEVEL GAUGE WITHOUT THEMOMETER	1
4	15-00682	HHSC, M8 X 1.25 X 25mm LONG, ZINC PLATED	2
5	15-00758	RETURN FILTER ASSEMBLY	1
6	15-00782	H.S. RESERVOIR TOP	1
7	15-00784	RESERVOIR WELDMENT	1
8	SEE	824 HYDRAULIC COOLER ASSEMBLY	1
9	SEE	824 HYDRAULIC MANIFOLD SUBASSEMBLY	1
10	SEE	15-00785 - 824 HYDRAULIC MOTOR & PUMP ASSEMBLY	1
11	SEE	HYDRAULIC SUCTION FILTER ASSEMBLY	1
12	15-01102	HOSE SUCTION, 1" X 16.50" LONG	1
13	15-01103	HOSE SUCTION, 3/4" X 16.50" LONG	1
14	15-01106	HOSE RETURN, 1/2" X 17.25" LONG	1
15	15-01107	HOSE, COOLER TO MANIFOLD, 3/4" X 13.75" LONG	1
16	15-01108	HOSE PRESSURE,, 3/4" X 30.75" LONG	1
17	15-01114	HOSE, COOLER TO TANK, 3/4" X 37.00" LONG	1
18	15-01158	HOSE PRESSURE, 5/8" X 32.25" LONG	1
19	15-01165	NUT, M10 HEX FLANGE	2
20	15-01183	FITTING, 3/4" MALE PIPE TO 1-5/16" MALE JIC	1
21	15-01185	FITTING, MJ-MP 90 8-12	1
22	15-01393	LOCK WASHER, M6, DIN127 ZINC	20
23	15-01469	HEX HEAD BOLT M8 X 40mm STEEL	4
24	15-01601	M6, WASHER, ZINC PLATED	14
25	15-02166	DRAIN PLUG, O-RING BOSS 1/2"	1
26	H-3596	FLATWASHER, 1/4"	6

Parts List – Hydraulic Reservoir Assembly (cont'd)

27	H-3600	LOCK WASHER, 5/16"	6
28	15-02715	CAP, FILTER RETURN ASSEMBLY	1
29	15-02714	CAP RING, FILTER RETURN ASSEMBLY	1
30	15-00888	FILTER ELEMENT(MAIN) , FILTER RETURN ASSEMBLY	1
31	15-02629	BREATHER ELEMENT, FILTER RETURN ASSEMBLY	1
32	15-02537	FLANGE GASKET, FILTER RETURN ASSEMBLY	1


Parts List – Hydraulic Manifold Assembly



Parts List – Hydraulic Manifold Assembly (cont'd)


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-01157	824 MANIFOLD	1
2	15-01120	Valve, 4-WAY H CENTER 24 VDC	1
3	15-01113	CHECK VALVE T-5A 4 PSI SPRING CXFA XAN (CK1) *NB*	2
4	15-01140	COUPLING, MP-FP 90 4-4 MALE PIPE TO FEMALE PIPE 90	1
5	15-01118	VALVE, PROP. RELIEF BVPPM22-200-G24/HB4.5-Z11	1
6	15-01115	CHECK VALVE, 100PSI, T-5A SPRG-CXFA XFN (CK3)	1
7	15-01197	SHCS, M6 x 1.0 x 40mm, STAINLESS STEEL	4
8	15-00371	LOCK WASHER, M6, STEEL	4
9	15-00066	5/8" JIC-SAE 12 O-RING FITTING STRAIGHT	2
10	15-01133	FITTING, 1/2" ORB TO 1/2" JIC ADAPTER	1
11	15-01152	COUPLING MB-MJ 12-12 MALE BOSS TO MALE JIC	1
12	15-01116	Solenoid Valve Normally Open Un-loader	1
13	15-01117	Solenoid Coil, 24VDC DIN CONN	1
14	15-00061	FITTING, 5/8XJICX5/8 O-RING STRAIGHT	1
15	15-01147	MB-MJ 90 12-12 MALE BOSS TO MALE JIC 90	1
16	15-01141	FITTING, MALE PIPE-FEMALE ORB MP-FB 4-6	1
17	15-01119	CHECK VALVE, SUN HYDRAULICS P/N: CNCC XAN 080 IN	1
18	15-03072	MB-FP 90 DEGREE 4-4	1
19	15-01112	VALVE, SEQUENCE	1
20	15-01122	RELIEF VALVE, T-10A 100-3000 PSI	1
21	15-01121	TRANSDUCER, 0-750 PSI 0-10 VDC.SLDPRT	1
22	H-2011	GAUGE, 3000 PSI, HYDRAULIC PRESSURE	1

Parts List – Hydraulic Suction Filter Assembly




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-01180	Fitting JIC MB-MJ 16-12	1
2	15-01163	Fitting JIC MB-MJ 16-16	1
3	15-00781	Suction Access Plate	1
4	15-01131	Suction Filter 1" Nut Style	2
5	15-01102	Hose Suction 1.0" x 16.5	1
6	15-01103	Hose Suction .75" x 16.5"	1

Parts List – Return Filter Assembly



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-02715	Cap, Filter Assy Return	1
2	15-02714	Ring, Filter Assy Return Cap	1
3	15-00888	Hydraulic Filter Element	1
4	15-00758	Filter Assembly Return Hycon	1
5	15-01183	Fitting MB-MJ 16-12	1
6	15-01114	Hose, Cooler to Tank Return 37"	1

Parts List – Motor Pump Assembly




Parts List – Motor Pump Assembly (cont'd)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-01142	MB-MJ 90 5/8" - 3/4" MALE BOSS TO MALE JIC	1
2	15-01127	SPIDER, 824OT/WT	1
3	15-01126	COUPLER HALF, L095 (5/8 X 3/16)	1
4	15-01125	COUPLER HALF, L095 (1-1/8 X 1/4)	1
5	15-01124	COUPLER 8.5 "A" PUMP / 4.75 LONG	1
6	15-01123	PUMP 824 HS	1
7*	15-00077	MOTOR, 5 HP, 1800 RPM, 50/60 HZ, 208/440 V	1
8	15-00062	FITTING, 5/8XJICX5/8 O-RING 90	1
9	15-01143	COUPLER, MB-MJ 90 3/4" - 1" MALE BOSS TO MALE JIC 90	2

* For 575 Model machines, use part # 15-00394 (MOTOR, 5 HP, 575 V) -- in lieu of the MOTOR, 5 HP, 208/440 V shown above.

Parts List – Hydraulic Cooler Assembly



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	15-00783	BRKT, RESERVOIR COOLER MOUNT	1
2	15-01601	M6, WASHER, ZINC PLATED	4
3	15-01393	LOCK WASHER, M6, DIN127 ZINC	4
4	11-00319	SHCS, M6 x 1.0 x 20MM, STAINLESS	4
5	15-01132	COOLER, 824 H/S ECO 4	1
6	15-01147	MB-MJ 90 12-12 MALE BOSS TO MALE JIC 90	2

Decommissioning Your Machine

The decommissioning of a Haeger machine is a rare occurrence as older models themselves being relocated or sold to other facilities around the world. In the event a machine component requires replacement, we recommend recycling the old. Most countries have recycling programs for such components like computers, petroleum based fluids, metals and so on. Contact your local governing agency or recycling center for details on proper containment and/or disposal of the machine or used components.



Contact Haeger customer service department when your machine is no longer in use.